

**Norstar-Companion
MICS-XC 2.0
Installer Guide**

Norstar, Meridian and Companion are trademarks of
Northern Telecom

© Northern Telecom 1997

Norstar Programming Overlay

Show

Next

P0639666 Issue 02
Printed in Canada

Norstar Programming Overlay

Heading

Show

Back

Next

P0639666 Issue 02
Printed in Canada

Norstar Programming Overlay

Heading

Show

Back

Next

P0639666 Issue 02
Printed in Canada

Norstar Programming Overlay

Heading

Show

Back

Next

P0639666 Issue 02
Printed in Canada

Heading

Back

Contents

Regulations 1

- Federal Communications Commission (U.S. only) 1
- Companion Base Stations 1
- Activation (U.S. only) 1
- Safety 2

Norstar Companion basics 3

What's new with Norstar 5

- New equipment 5
- New programming design 5
- More "one-stop" programming 5
- New features 5

Planning the installation 7

- Planning checklist 7
- Required equipment and supplies 7
- Configuring Station Modules 7
- Configuring expansion modules 8
- ICS numbering 14

Installation 17

- Installation checklist 17
- Connecting expansion modules 18
- Installing Remote Power Interconnect (RPI) units 18
- Installing Base Stations 29
- Installing portable telephones 33
- Installing external antennas and lightning surge arrestors 34

Powering up the system 41

Programming 43

- Programming overview 43
- Programming tools 45
- Template defaults 49
 - Passwords defaults 49
 - System prgrming defaults 50
- Startup programming 51
 - Performing Startup 51

- Changing the default template 52
 - Entering programming 53
 - Entering programming for installers 53
 - Entering programming for system coordinators 53
 - Entering programming using other passwords 54
 - Norstar features 54
 - Portable features 54
 - External paging system (customer supplied) 55
 - Registration password 56
 - Changing the Registration password 56
 - Companion programming 58
 - Registration 58
 - Radio data 60
 - System logical identifier (LID) 63
 - Software keys (U.S. only) 64
-

Registering individual portables 69

- Registering the C3050 69
 - Deregistering the C3050 71
 - Measuring RSSI for a C3050 72
 - Deregistering the C3020 (Canada only) 75
 - Measuring RSSI for a C3020 (Canada only) 76
 - After registering the portables 78
-

Testing 81

- Testing the Companion portable telephones 81
 - Testing the Base Stations 81
 - Testing the system coverage 82
-

Troubleshooting 83

- Problems with a portable telephone 83
 - Problems with a Base Station 83
 - Problems with an RPI 86
 - Problems with wireless communication 87
 - Alarm codes 89
 - Event messages 94
-

Specifications 99

- Norstar Companion system components 99

Upgrading your system 103

Adding Companion to a mini, midi, maxi, or mega system
103

Upgrading an RPI-8 to an RPI-16 103

Glossary 105

Index 113

Regulations

Federal Communications Commission (U.S. only)

The Federal Communications Commission (FCC) has designated UTAM Inc. to manage the installation and relocation of Unlicensed Personal Communication Services (UPCS). This includes Norstar Companion Base Stations and Portable Telephones.

Companion Base Stations

The radiated and conducted emissions of the Companion Base Station radios shall not exceed the requirements for digital cordless telephones as outlined in FCC Part 15-subpart D (DOC RSS-130 documents in Canada). The Base Station should not be installed in ducts, plenums, or hollow spaces used to transport environmental air.

Note: In Canada, Base Stations may be installed where the duct, plenum or hollow space is created by a suspended ceiling having lay-in panels or tiles, in accordance with CE Handbook Rule 60-402.

Activation (U.S. only)

Wireless communication on a Companion system cannot be activated until installation at its authorized location is verified and approved by UTAM Inc. This system is equipped with an automatic mechanism for disabling wireless operation in the event it is moved outside the area where its operation has been approved by UTAM Inc. This mechanism complies with FCC requirements.

Safety



Do not connect the administration set or Base Stations directly to a CO line.

Doing so may result in equipment damage.



The Norstar administration set and Base Stations must not be used as off-premises equipment.

Installers should check the lightning surge arrestors at the cable entry point to the building with special attention to the grounding. Any problems should be reported to your telephone company in writing.

Because Norstar administration sets and Base Stations are not lightning protected, do not install them outside the building.

Norstar Companion basics

Norstar Companion provides mobility in the workplace. With Companion, your telephone can go with you, allowing you to make and receive calls while on the move. Calls that used to ring just at your desk can also appear and ring at your portable (this is called twinning). Twinning works provided the portable is assigned the desk telephone DN as an Answer DN.

The portable telephones can access most Norstar business features such as call forward, call transfer, conferencing, and voice mail. Companion on Norstar consists of four main components:

ICS and Norstar XC 2.0 software - Norstar XC 2.0 software manages the telephone traffic between Companion Base Stations and portable telephones. Base Stations are connected to the ICS in the same way as Norstar sets. Companion portable telephones are registered on the system and do not take up any ports on the system. Up to 60 portable telephones and up to 32 Base Stations (32 cells) can be connected to the system.

Companion Base Stations - Base Stations are positioned throughout the coverage area to send and receive calls between the portable telephones and the ICS. The Base Stations use advanced digital radio technology and support handoff and roaming within the coverage area which can be up to 160,000 square meters (three million square feet) when using the maximum number of Base Stations.

Before the Base Stations can be used in the United States, UTAM codes must be obtained and entered using an administration terminal or Norstar Remote Utilities (NRU). Please see Software keys (U.S. only) on page 64 for more detailed information.

Companion Portable Telephones - The portable telephones used with your Norstar system are small, lightweight units with fully digital performance to provide clear voice quality. Companion portable telephones feature a three line, 16-character, alphanumeric display. For more information on the portable used with your MICS XC 2.0 system, refer to the *Companion Portable Telephone User Guide* that comes with it.

Before the portables can be used in the United States, portable credits must be obtained. Please refer to Software keys (U.S. only) on page 64.

Administration and Maintenance Tools - Programming of the Companion system is easily and quickly done through an M7310 or M7324 digital telephone set. You can assign portable telephones to the system, check Base Station parameters, and enable and disable registration.

System programming can also be done using Norstar Remote Utilities (NRU) software on a personal computer (PC).

Companion Diagnostic Software allows diagnostics to be run on the wireless system and can be done either locally or remotely via a PC.

Norstar Voice Mail - If you are using Norstar Voice Mail with your Companion system, Version 3.0 is recommended as a minimum Voice Mail software version.

For information on how to access Norstar Voice Mail using your Norstar Companion portable, refer to the *Portable Telephone Feature Card* that comes with it.

What's new with Norstar

New equipment

The Norstar 0X32 system has new equipment with improved performance to meet your growing telecommunication needs.

Note: Previous users of the Norstar 0X32 system should note that the Key Service Unit (KSU) has been renamed the Integrated Communication System (ICS).

New programming design

Operations, administration and maintenance programming for Norstar-PLUS Modular ICS has been redesigned to make installation and adds, moves, and changes on the system easier. The reorganization reflects the priorities of installers, customer service representatives and system coordinators.

Because programming is now done only on sets with a two-line display, users will have more flexibility and power when installing and making changes to the Norstar system. A telephone with a single-line display cannot be used for programming.

More "one-stop" programming

With the addition of new programming headings and subheadings, settings for features have been grouped together in one place. There are also parts of programming which have been repeated under one or more headings to help make programming easier. For example, you can program all the restriction filters that are available under both Lines and Terminals&Sets because those settings are used in both places.

New features

Call Park

With Norstar-PLUS Modular ICS 2.0 you can suspend a call so that it can be retrieved from any telephone in your system. Call Park is helpful for switching calls between your portable and your desk telephone.

For more information refer to *Norstar-PLUS Modular ICS 2.0 System Coordinator Guide*.

Page

Norstar-PLUS Modular ICS 2.0 includes the Page feature which allows you to page an individual telephone, several terminals, external speakers, or the entire system.

For more information refer to *Norstar-PLUS Modular ICS 2.0 System Coordinator Guide*.

Routing codes

Norstar-PLUS Modular ICS 2.0 allows a portable telephone user to make calls using routing codes.

For more information about routing codes refer to *Norstar-PLUS Modular ICS 2.0 Installer Guide*.

Planning the installation

Planning checklist

- ☐ Verify that you have approval from UTAM Inc. (U.S. only)
- ☐ Verify that a site planner determined Base Station locations and recorded them in the *Provisioning Record*.

Required equipment and supplies

- ☐ Companion portable telephones
- ☐ Companion Base Stations
- ☐ Companion Remote Power Interconnect device
- ☐ Companion ID Labels (See Step 1: Obtain the Companion ID on page 65.)

Configuring Station Modules

When installing wireless capabilities, use only the last two (or highest numbered) ports for connecting the Companion Base Stations.

Each Station Module allows you to connect up to 16 additional Norstar telephones to the system.

Maximum number of Norstar telephones on a system

mini	midi		maxi				mega			
ICS	SM3	SM4	SM5	SM6	SM7	SM8	SM9	SM10	SM11	SM12
32	48	64	80	96	112	128	144	160	176	192

Each Station Module that is used for Norstar Companion allows you to connect up to 16 Base Stations to the system.

Maximum number of Norstar Companion Base Stations on a system

mini	midi		maxi		mega	
ICS	SM3	SM4	SM7	SM8	SM13	SM14
16	16	32	16	32	16	32

Configuring expansion modules

With the addition of an Expansion Cartridge or a Combo Cartridge in the ICS, you can add Trunk Modules and/or Station Modules to increase your system capacity.

Previous users of the Norstar 0X32 system should note that the Key Service Unit (KSU) has been renamed the Integrated Communication System (ICS).

Installed in ICS	Additional modules allowed		
	Trunk	Station	Maximum
XC system Combo cartridge (6-port + Services) (maxi)	6	6	6
Combo and 6-port cartridges (mega)	6	12*	12
Two Combo cartridges (mega)	6	12*	12
Two 6-port cartridges (mega)	6	12*	12

*The last two ports are reserved for Companion use only.

Note: For each type of expanded system above, Norstar Companion capability is supported. For wireless capability you must install Norstar-PLUS MICS-XC software.

On a mini system

Note: Port 1 and 2 are on the ICS.


On a “mini” or non-expanded system, port 1 on the ICS (station ports 101 to 132) is used for both Base Stations and Norstar sets. No fiber ports are used since no Station Module is required. Directly connect your Base Stations or Norstar sets to port 1 on the ICS via a wiring distribution panel.

On a midi system

On midi and maxi systems, the highest numbered ports can be used for *both* Base Stations and Norstar sets. Therefore, sets and Base Stations can share the two highest numbered fiber ports.

A system expanded to 4 ports (midi size) includes one 2-port expansion cartridge with fiber ports numbered 3 and 4, and 1 and 2 on the ICS. The Base Stations *must* be physically connected (via a Station Module) to fiber ports 3 and 4 only. If only one Station Module supporting Base Stations is required, connect it to the highest-numbered port (port 4).

Two-port Expansion Cartridge



On a maxi system


A system expanded to 8 ports (maxi size) includes one 6-port expansion cartridge with fiber ports numbered 3 to 8, and 1 and 2 on the ICS. The Base Stations *must* be physically connected (via a Station Module) to fiber ports 7 and 8 only. There is a maximum number of two Station Modules per Base Station. See "Six-port Expansion Cartridge with Companion" on page 10.

If only one Station Module supporting Base Stations is required, connect it to the highest-numbered port (port 8).



Tips - *If Both ports 7 and 8 are used for connecting Station Modules supporting Base Stations, connect Trunk Modules starting at port 6 and working down. Connect Station Modules (for Norstar desk sets) beginning at port 3 and working up.*

Six-port Expansion Cartridge with Companion



On a mega system


Keep in mind that 10 station modules is the limit for regular Norstar sets, and 2 station modules for Companion Base Stations is the limit on an XC 2.0 configuration.

For example, a system expanded to 14 ports (mega size) includes two 6-port expansion cartridges with fiber ports numbered 3 to 14 on the expansion cartridges, and 1 and 2 on the ICS. The Base Stations *must* be physically connected to fiber ports 13 and 14 only. See "12-port Expansion Cartridge with Companion" on page 12.




Tip - *In the fully expanded mega configuration, Station Modules 13 and 14 are reserved for Base Stations only.*

12-port Expansion Cartridge with Companion



Routing fiber cables



ICS numbering

Non-expanded system (ICS alone) numbering

Module #	Lines	Line ports	B1 DN	B2 DN	DN ports	Base Station ports	Portable DN
ICS (#2)	001-048	201-248	— —	— —	— —	— —	637-696
ICS (#1)	— —	— —	21-52	53-84	101-132	101-132	637-696

Two-port Expansion Cartridge and ICS numbering

Expansion module #	Lines	Line ports	B1 DN	B2 DN	DN ports	Base Station ports	Portable DN
#4	049-072	401-412	269-284	333-348	401-416	401-416	637-696
#3	073-096	301-312	253-268	317-332	301-316	301-316	637-696
ICS (#2)	001-048	201-248	— —	— —	— —	— —	— —
ICS (#1)	— —	— —	221-252	285-316	101-132	— —	— —

Six-port Expansion Cartridge and ICS numbering

Expansion module #	Lines	Line ports	B1 DN	B2 DN	DN ports	Base Station ports	Portable DN
#8	049-072	801-812	333-348	461-476	801-816	801-816	637-696
#7	073-096	701-712	317-332	445-460	701-716	701-716	637-696
#6	097-108	601-612	301-316	429-444	601-616	— —	— —
#5	109-120	501-512	285-300	413-428	501-516	— —	— —
#4	121-132	401-412	269-284	397-412	401-416	— —	— —
#3	133-144	301-312	253-268	381-396	301-316	— —	— —
ICS (#2)	001-048	201-248	— —	— —	— —	— —	— —

ICS (#1)	---	---	221- 252	349- 380	101- 132	---	---
----------	-----	-----	-------------	-------------	-------------	-----	-----

Twelve-port expanded system and ICS numbering

Expansion module #	Lines	Line ports	B1 DN	B2 DN	DN ports	Base Station ports	Portable DN
#14	---	---	---	---	---	1401-1416	637-696
#13	---	---	---	---	---	1301-1316	637-696
#12	---	---	397- 412	589- 604	1201- 1216	---	---
#11	---	---	381- 396	573- 588	1101- 1116	---	---
#10	---	---	365- 380	557- 572	1001- 1016	---	---
#9	---	---	349- 364	541- 556	901- 916	---	---
#8	049- 072	801- 812	333- 348	525- 540	801- 816	---	---
#7	073- 096	701- 712	317- 332	509- 524	701- 716	---	---
#6	097- 108	601- 612	301- 316	493- 508	601- 616	---	---
#5	109- 120	501- 512	285- 300	447- 492	501- 516	---	---
#4	121- 132	401- 412	269- 284	461- 476	401- 416	---	---
#3	133- 144	301- 312	253- 268	455- 460	301- 316	---	---
ICS (#2)	001- 048	201- 248	---	---	---	---	---
ICS (#1)	---	---	221- 252	413- 444	101- 132	---	---



Tip - Port 3 is the bottom fiber cable port on the two-port and the six-port Expansion Cartridge in slot 2. Port 9 is located on the leftmost Expansion Cartridge in slot 1.

Refer to Norstar-PLUS Modular ICS 2.0 Installer Guide for details.

Installation

Installation checklist

When installing a Norstar system with Companion components, follow this installation checklist:

- ☐ mount the Integrated Communication System (ICS) and expansion modules (as required)
- ☐ install the Feature Cartridge
- ☐ install the Expansion Cartridge and Trunk Cartridges (as required)
- ☐ connect the expansion modules*
- ☐ complete the wiring
- ☐ install the emergency telephone(s)
- ☐ install the Norstar telephones
- ☐ install the single-line telephones
- ☐ install the optional equipment
- ☐ install the Remote Power Interconnect units*
- ☐ install the Base Stations*
- ☐ install the portable telephones*
- ☐ install the external antennas and lightning surge arrestors*
- ☐ power up the system

* Procedures that are specific to Companion are included in this document. For all other procedures, see the *Norstar-PLUS Modular ICS 2.0 Installer Guide*.

Connecting expansion modules



Installation planning is required for Base Stations.

Before connecting any Station Modules required for Base Stations, please see "Configuring expansion modules" on page 8 for more information on the installation rules involved.

In order to keep the default port and extension numbering, connect Trunk Modules to the Expansion Cartridge beginning at the top and working down; connect Station Modules to the Expansion Cartridge beginning at the bottom and working up.

Installing Remote Power Interconnect (RPI) units



The RPI unit should have the DC backup power supplied by a UL listed UPS.

The UPS should have an output voltage rating of 44 to 52 V DC, with a maximum fault current limit of 6 A to protect the RPI's output wiring. Otherwise, it may be necessary to use class 1 wiring.




The RPI units must always be installed inside a building.

The AC outlet powering the RPI should be installed near the equipment and should be easily accessible.

The length of the RPI cord, from the outside surface of the unit to the plug, should be a minimum of 1.3 m (4 1/2 ft.) and a maximum of 4.6 m (15 ft.).

RPI unit



There are two versions of the RPI unit: the RPI-8 BIX UL, which supports up to eight Base Stations; and the RPI-16 BIX UL, which supports up to 16 Base Stations. Each RPI has a connection board and either one (RPI-8 BIX UL) or two (RPI-16 BIX UL) power supply units (PSUs). The maximum input power consumption of an RPI is 240 W. If a UPS 48 V DC backup source is used, the maximum input power requirement of the RPI is 135 W.

You can upgrade an RPI-8 BIX UL to an RPI-16 BIX UL by installing a second PSU to the RPI-8 BIX UL. See “Upgrading an RPI-8 to an RPI-16” on page 103.

If RPIs are distributed throughout the site, the number and type of RPIs will depend on the placement and powering plan of the Base Stations.

To determine how many Base Stations and how many PSUs you need for the number of Base Stations, use the following table:

RPI Requirements

Base Stations	RPI-16 and RPI-8 required	PSUs required
1–8	1 RPI-8	1 PSU
9–16	1 RPI-16	2 PSUs
17–24	1 RPI-16 and 1 RPI-8	3 PSUs
25–32	2 RPI-16	4 PSUs

Mounting the RPI unit


1. Position the screw holes for the RPI using the dimensions shown in the following figure.

To provide adequate ventilation and to prevent overheating, leave a clearance of at least 125 mm (5 in.) around the RPI.

If you are mounting two RPIs, one above the other, leave a clearance of at least 300 mm (12 in.) between them to provide adequate ventilation and to prevent overheating.


Mount RPIs at least 300 mm (12 in.) from the ceiling.

RPI mounting holes



2. Insert wall plugs in the holes.
3. Partially screw in two #10 50-mm (2-in.) screws for the keyholes.
4. Open the hinged cover with a screwdriver by pushing in and then down to release the catch on the right side. You can remove the cover by lifting it off its hinges.


Opening the RPI cover



5. Hang the RPI on the two keyhole screws and tighten them.
6. Install the remaining two screws.
7. Feed the power cord through the bottom of the RPI and route it through the clip and around the strain relief support as shown in the following figure.
8. Route the power cord to the input power socket just to the left of PSU 1. Connect the plug to the socket.

Note: Distinctive labeling of RPIs may help to diagnose any future problems.

RPI components



Unplug the RPI power cord.

Do not apply power to the RPI until its installation and wiring are complete.

The RPI-8, which has only one power supply unit, has grounding straps and plates fitted so it can be upgraded to an RPI-16 (see illustration "RPI components").

Wiring the RPI



Do not run unprotected power cables outdoors.

The maximum two-way DC loop resistance for power pairs, including interconnections for each Base Station, is 90 ohms. You will need one or two power pairs between the RPI and the Base Station, depending on the wire size of the power pairs and the distance between the Base Station and the RPI.

Maximum power cabling distance (approximate)

Depending on the size of cable you are using, you should remember the maximum cabling distances allowed between the RPI and the Base Station.

Wire size	Single-pair	Double-pair
0.6 mm (22 AWG)	450 m (1,500 ft.)	900 m (3,000 ft.)
0.5 mm (24 AWG)	300 m (1,000 ft.)	600 m (2,000 ft.)




When using two power pairs, ensure they are connected with the same polarity.

RPI Connector Overview

The following illustration shows where the input and output connectors are located on the RPI connector board.

RPI connector board



Output connections


Feed the output pairs in through the bottom of the RPI and route the pairs to the output connectors as shown in the following illustration. If only one pair is used for powering a Base Station, connect the power pair to -PWR(1) and +PWR(1). If two pairs are used to power a Base Station, connect one pair to -PWR(1) and +PWR(1), and the second pair to -PWR(2) and +PWR(2).



Ensure both pairs have the same polarity.

Connecting two power pairs with opposing polarities may damage the Base Station and RPI.


Output connector pinout



Input connections

Feed the TCM input pairs from the ICS distribution frame through the top of the RPI and route the pairs to the input connectors (IBIX1 to IBIX4) as shown in the following illustration. There may be fewer than 16 input pairs in any given RPI installation.

Input connector pinout



Input wiring

Connector	Pin	Signal	Output connector
IBIX1	1, 2	TCM 1	OBIX1
	3, 4	TCM 2	OBIX2
	5, 6	TCM 3	OBIX3
	7, 8	TCM 4	OBIX4
IBIX2	1, 2	TCM 5	OBIX5
	3, 4	TCM 6	OBIX6
	5, 6	TCM 7	OBIX7
	7, 8	TCM 8	OBIX8
IBIX3	1, 2	TCM 9	OBIX9
	3, 4	TCM 10	OBIX10
	5, 6	TCM 11	OBIX11
	7, 8	TCM 12	OBIX12
IBIX4	1, 2	TCM 13	OBIX13
	3, 4	TCM 14	OBIX14
	5, 6	TCM 15	OBIX15
	7, 8	TCM 16	OBIX16

RPI-8 BIX wiring chart

Pin	RPI Connector Board	Label	Wire color
26	OBIX1 BS1	-PWR	White-Blue
1			Blue-White
27		TCM	White-Orange
2			Orange-White
28		+PWR	White-Green
3			Green-White
29	OBIX2 BS2	-PWR	White-Brown
4			Brown-White
30		TCM	White-Slate
5			Slate-White
31		+PWR	Red-Blue
6			Blue-Red
32	OBIX3 BS3	-PWR	Red-Orange
7			Orange-Red
33		TCM	Red-Green
8			Green-Red
34		+PWR	Red-Brown
9			Brown-Red
35	OBIX4 BS4	-PWR	Red-Slate
10			Slate-Red
36		TCM	Black-Blue
11			Blue-Black
37		+PWR	Black-Orange
12			Orange-Black
38	OBIX5 BS5	-PWR	Black-Green
13			Green-Black
39		TCM	Black-Brown
14			Brown-Black
40		+PWR	Black-Slate
15			Slate-Black

Pin	RPI Connector Board	Label	Wire color
41	OBIX6 BS6	-PWR	Yellow-Blue
16			Blue-Yellow
42		TCM	Yellow-Orange
17			Orange-Yellow
43		+PWR	Yellow-Green
18			Green-Yellow
44	OBIX7 BS7	-PWR	Yellow-Brown
19			Brown-Yellow
45		TCM	Yellow-Slate
20			Slate-Yellow
46		+PWR	Violet-Blue
21			Blue-Violet
47	OBIX8 BS8	-PWR	Violet-Orange
22			Orange-Violet
48		TCM	Violet-Green
23			Green-Violet
49		+PWR	Violet-Brown
24			Brown-Violet

RPI-16 BIX wiring chart

Pin	RPI Connector Board	Label	Wire color
26	OBIX9 BS9	-PWR	White-Blue
1			Blue-White
27		TCM	White-Orange
2			Orange-White
28		+PWR	White-Green
3			Green-White
29	OBIX10 BS10	-PWR	White-Brown
4			Brown-White
30		TCM	White-Slate
5			Slate-White
31		+PWR	Red-Blue
6			Blue-Red

Pin	RPI Connector Board	Label	Wire color
32	OBIX11 BS11	-PWR	Red-Orange
7			Orange-Red
33		TCM	Red-Green
8			Green-Red
34		+PWR	Red-Brown
9			Brown-Red
35	OBIX12 BS12	-PWR	Red-Slate
10			Slate-Red
36		TCM	Black-Blue
11			Blue-Black
37		+PWR	Black-Orange
12			Orange-Black
38	OBIX13 BS13	-PWR	Black-Green
13			Green-Black
39		TCM	Black-Brown
14			Brown-Black
40		+PWR	Black-Slate
15			Slate-Black
41	OBIX14 BS14	-PWR	Yellow-Blue
16			Blue-Yellow
42		TCM	Yellow-Orange
17			Orange-Yellow
43		+PWR	Yellow-Green
18			Green-Yellow
44	OBIX15 BS15	-PWR	Yellow-Brown
19			Brown-Yellow
45		TCM	Yellow-Slate
20			Slate-Yellow
46		+PWR	Violet-Blue
21			Blue-Violet

Pin	RPI Connector Board	Label	Wire color
47	OBIX16 BS16	-PWR	Violet-Orange
22			Orange-Violet
48		TCM	Violet-Green
23			Green-Violet
49		+PWR	Violet-Brown
24			Brown-Violet
50			
25			

Installing Base Stations

Before installing wireless equipment, ensure that a site planner has determined Base Station locations and recorded them in the *Provisioning Record*.



Each Base Station must be installed within 1230 m (4000 ft., TCM wiring length) of the ICS or Base Station Module.

To optimize seamless hand-off, the difference in TCM wiring length between neighboring Base Stations should not exceed 300 m (1,000 ft.).

Before installing or relocating wireless equipment in the United States, verify that you have approval from UTAM Inc. by calling the Northern Telecom Customer Response Center at **1-800-321-2649**. You will be given codes and credits that are necessary to activate the system. Please see "Software keys (U.S. only)" on page 64 before calling.

Positioning a Base Station

Avoid installing Base Stations on large concrete or marble columns since this affects radio coverage. If possible, place the Base Station at least 1 m (40 in.) from such columns. Try not to mount a Base Station where metalwork is near the antenna housings. Be careful not to damage existing wiring or panels.

Do not position Base Stations in ducts, plenums, or hollow spaces used to transport environmental air except where the duct, plenum or hollow space is created by a suspended ceiling having lay-in panels or tiles. If more than one Companion Base Station is required in one cell to meet traffic demands, position all the Base Stations at the same cell center a minimum of 1.35 m (54 in.) apart from the center of one Base Station to the center of another.



Never mount Base Stations in rows.

Position Base Stations away from an office area or where a portable is used by at least the amounts shown in the following table. Installing the Base Station on the ceiling or high on walls helps to maintain these minimum distances.


Minimum distance between office areas and Base Stations

Number of Base Stations in the cell	Minimum distance between office areas and Base Stations
1	1 m (40 in.)
2	1.4 m (56 in.)
3	1.8 m (72 in.)
4	2 m (80 in.)

Mounting a Base Station

Base Stations can be mounted on a wall or on a ceiling (when mounting on a wall, install them with their covers at the bottom, as shown in the following illustrations). Allow for clearances around the Base Station as indicated in the following illustration.

Clearance for the Base Station



To mount a Base Station:


1. Fasten the bracket into position using two #8 38-mm (1 1/2-in.) screws.
2. Route the cable from the ICS through the top (or bottom) opening.
3. Wind any excess cable around the posts to secure it, then fasten it under the strain relief.
4. Connect the wires to the BIX connector on the bracket termination board as shown in the following illustration.

The polarity of the TCM connections is not important. If two power pairs are brought in, they must be connected with the same polarity to the Base Station bracket termination board.



Ensure that the RPI is off before connecting power pairs to the Base Station.

Bracket termination board



5. Mount the Base Station onto the bracket, snapping it into position.
6. Connect the power RJ11 jumper lead to the RJ11 jacks on the termination board and the Base Station.
7. For plug-top power supplies only, connect the power supply connector to the Base Station power connector. Make sure the Base Station is powered by a class 2 plug-top power source only.




Inserting the power supply connector in the wrong direction may damage the plug-top power supply and the Base Stations.

Position the power supply connector in the proper direction and push it into place securely.

8. Record the associated ICS port number in the space provided on the printed label affixed on the lower right corner of the mounting bracket.

Include the labeling information for each Companion Base Station on the completed installation floor plans.
9. Slide the cover onto the bracket, using the guide to position it properly. Snap it into place.

Sliding cover onto bracket



Installing portable telephones

To use Norstar Companion portables, you must first install radio Base Stations to transceive radio signals to and from the portable telephones. See "Installing Base Stations" on page 29.

Companion Portable Telephones are installed differently than traditional Norstar sets. There are no direct connections between the portables and the Norstar system. Do the following:

- Install the batteries and battery charging units for each portable, using the instructions that come with the portable.
- Register each Companion portable for use with the Norstar system. For complete instructions, see the Registration information beginning on page 58.

Note: Up to 60 portables can be installed on a Norstar wireless system. Each portable telephone must be registered before it can be used. By default, no Companion portables are assigned to the DNs. The range of portable extensions available for wireless registration is 637 to 666. (This means that the digit 6 is not available as a destination code.)

Installing external antennas and lightning surge arrestors

When installing external antennas and lightning surge arrestors:

- The antenna should always be mounted vertically (see figure on page 35).
- Use #8, 12 mm to 50 mm ($\frac{1}{2}$ -in. to 2 in.) screws to mount the antenna bracket and lightning surge arrestor bracket to the wall.
- Always ensure that the antenna is clear of any adjacent obstruction, particularly metal. If more than one external antenna is used at a cell center, space them at least 1 m (40 in.) apart to avoid radio interference problems.
- When running the coaxial cable inside or outside, do not kink, stretch, or crush the cable. This will seriously affect its performance. The minimum recommended bending radius is 200 mm (8 in.).
- The coaxial cable length must not exceed 10 m.
- Use RG-58AU coaxial cables to connect the antennas to the Base Stations.
- Depending on site requirements, a proprietary extension cable can be attached between the lightning surge arrestor and the antenna or between the lightning surge arrestor and the Base Station. The total cable length should always be kept as short as possible and the recommended extension cable used only if absolutely necessary.
- You must install a lightning surge arrestor for each outdoor external antenna.



FCC requirements.

In the United States, the FCC requires that only certified antennas be connected to Companion Base Stations.




Do not install the external antenna or the lightning surge arrester during an electrical storm.

Always turn off the Base Station power before connecting the coaxial cable of an outdoor external antenna.

Always install the lightning surge arrester at the cable entry point into the building.

Connect the lightning surge arrester to ground before connecting the coaxial cable.

Installed antenna and lightning surge arrester



To ensure only recommended antennas are used:

- the external antenna connectors on the Base Station are special proprietary BNC connectors
- antennas are supplied with cables already attached and terminated with special proprietary BNC plugs to join with the connector on the Base Station
- cables are not supplied with exterior antennas

Planning for an outdoor external antenna


When planning to install an outdoor external antenna:

- Locate the antenna on the external wall of the building.
- Keep the outdoor external antenna as close as possible to the Base Station serving it (the Base Station must be inside). The recommended mounting height is 4 to 5 m (13 to 16 ft.) above ground.
- Always install a lightning surge arrestor between an outdoor antenna and a Base Station.

Installing an outdoor external antenna

To install an outdoor external antenna, follow these steps:

1. Drill a hole for the coaxial cable.
2. Install conduit for the antenna cable according to local building and wiring codes.
3. Screw the antenna bracket to the wall so that the antenna will be positioned vertically on the exterior wall of the building.
4. Loosen the nut on the antenna.
5. Slide the antenna into the slot of the bracket and tighten the nut.
6. Feed the coaxial cable through the wall to the lightning surge arrestor on the interior wall.


Antenna with antenna bracket**Installing a lightning surge arrestor**

Install the lightning surge arrestor to protect the Companion components from electrical surges.

To install a lightning surge arrestor, follow these steps:

1. Mount the lightning surge arrestor on the interior wall as close as possible to the entry point of the coaxial cable from the outdoor external antenna.

Lightning surge arrestor and bracket



2. Before you connect the ground lead to the lightning surge arrestor, attach it to an approved ground.



Tip - The recommended wire gauge is 4 mm (6 AWG). Connect the ground lead to the building ground. Do not connect to a ground rod or series of ground rods. If you cannot connect the ground lead to the building ground, connect it to the steel frame of the building. The connection should be no more than 1.8 to 3 m (6 to 10 ft.).

You can also connect the ground lead to the 120 V AC conduit (which is connected to the building ground), but this is not a preferred installation.

The connector between the antenna and the lightning surge arrestor and between the lightning surge arrestor and the Base Station is a proprietary BNC connector and requires alignment before a connection can be made.

3. Route and connect the coaxial cable from the outdoor external antenna to the lightning surge arrestor.
4. Route and connect the coaxial cable from the lightning surge arrestor to the appropriate Base Station connector.

Powering up the system

If you added a Base Station that requires a software update, the system will begin downloading the software to the Base Station. The Administration Terminal display shows **BS-1 Dload Start.** Press **CLEAR** to clear the message. When the Base Station software is downloaded, the Administration Terminal shows **BS-1 Dload Done.** Press **CLEAR** to clear the message. Some Base Stations may not be powered up at the same time, and this message will repeat at the beginning of each download.

In the United States, the display will show one of the following messages after powering up:

If display shows	See
UTAM code req'd	System logical identifier (LID) on page 63.
UTAM test failed	Alarm codes on page 89 in the Troubleshooting chapter.



A loss of UTAM information occurs when upgrading US MICS-XC systems.

UTAM Recovery Codes are required.

Programming

Programming is performed by the installer or the customer service representative, and it allows you to change settings for the entire Norstar system, plus settings for individual telephones and external lines. Most of the settings can also be programmed by a system coordinator who has a “plus” (SysCoord+) password.



Programming affects system operation.

Only a qualified installer or customer service representative should perform startup, installation and maintenance programming. Some of the settings affect the correct operation of the system.

Programming overview

Programming access is controlled by four passwords.

- Installer password – allows you to see and change any item in programming.
- System Coordinator Plus password – provides knowledgeable users with access to all but a few sensitive areas of programming.
- System Coordinator password – used to view and change the settings that are part of day-to-day administration of the Norstar system.
- Basic password – used with a limited number of feature codes to change programming and control system services.

The Programming overview tables show the programming access for installers and system coordinators. For information on programming the passwords, see the *Norstar-PLUS Modular ICS 2.0 Installer Guide*.

For information about Companion programming using the System Coordinator and Basic passwords, see the *Norstar-Companion MICS-XC 2.0 System Coordinator Guide*.

Programming overview of XC 2.0 using the Installer and System Coordinator Plus password

Startup	Sys speed dial	Software keys*
Template	Passwords	SysID
Start DN	COS pswds	Password keys
Terminals&Sets	Call log pswds	Hardware
Line access	Progming pswds	Cards on KSU
Capabilities	Reg. pswd	Cards on Mod 3
Name	Time&Date	Cards on Mod 4
User preferences	System prgming	Cards on Mod 5
Restrictions	Change DN's	Cards on Mod 6
Telco features	Featr settings	Cards on Mod 7
Lines	Direct-dial	Cards on Mod 8
Trunk/Line data	CAP assign-ment	Maintenance
Name	Access codes	System version
Restrictions	Remote access	Port/DN status
Telco features	Change DN type	Module status
Services	Companion	Sys test log
Ringing service	Rec'd # length	Sys admin log
Restrn service	DN length	Network evt log
Routing service	Telco features	Provisioning
Common settings	VM'sg ctr tel#s	Tests
		CSU stats

* USA-MICS-XC 2.0 system only

Shaded items are seen only if you are using the Installer password.

Programming overview of XC 2.0 using the System Coordinator password

Terminals&Sets	Lines	Passwords
Capabilities	Name	Call log pslds
Name	Services	Progrming pslds
User preferences	Ringing service	Reg. psld
Restrictions	Restrn service	Time&Date
Telco features	Routing service	System prgrming
	Sys speed dial	Companion

Programming tools



A Norstar telephone

Programming is done at an M7310 or M7324 telephone. Use the buttons on the telephone to program a setting or to request a specific programming action. Norstar guides you step-by-step with instructions on the telephone display while you are programming.

The programming overlay

The programming overlay is a paper cutout that labels four telephone buttons used during programming. The programming overlay is provided at the front of this guide.

Placing the programming overlay



Norstar Programming Overlay				
Heading				Show
Back				Next


PO080665 Issue 02
Printed in Canada

The indicators (▶) on the M7310 or M7324 telephone show which buttons can be used at that programming step. The functions on these buttons allow you to move through the headings and subheadings of Norstar programming.

- | | |
|---------|---|
| Heading | moves to a higher level in the hierarchy of headings and subheadings. |
| Show | moves to a lower level in the hierarchy of headings and subheadings, or begins programming for a heading or subheading. |
| Next | moves forward at the same level in the hierarchy of headings and subheadings. |
| Back | moves backward at the same level in the hierarchy of headings and subheadings. |

The Norstar display buttons

Display buttons on the M7310 and M7324 telephones perform many functions. Depending on where you are in programming, one, two, or three display buttons may be available at any one time. Press one of the display buttons to select the function that you want.



Special characters on the display

When a triangle (▶) is at the end of a programming heading or subheading, it means you can press Show to see settings.

When an ellipsis (...) is at the end of a heading or subheading, it means you can press Show to see the setting for that heading.

The Norstar Programming Record

The *Programming Record* provides a convenient way to record what you have programmed. It also helps you to plan your programming.

Pages from the record may be photocopied as necessary for programming many telephones or lines.

Exiting programming

Norstar stores your changes automatically as soon as you alter any settings; you do not need to "save" your changes.

Press **[Rls]**. The display briefly reads **End of session**.

Viewing your programming updates

If any changes you have made to programming have not taken effect yet, you will see an **UPDATE** display button when you leave programming. The display will show you how many telephones have not been updated yet because the system is busy with other programming or the telephone is in use.

Press **DNs** to see the specific extensions where programming changes have not been updated. Items will disappear from the list as they are updated, and **UPDATE** will disappear once all changes are complete.

Entering numbers

Numbers are entered from the Norstar telephone dial pad. The backspace display button may be used to edit the number.

A line number must always be entered as a three-digit number. Line numbers from 10 to 99 must be entered with a leading zero (line 020, for example). Similarly, line numbers less than 10 must be entered with two leading zeros (line 002, for example).

Internal telephone numbers, also referred to as directory numbers (DNs), can be three to seven digits long. The DN length can be changed in programming.

Template defaults

This section describes only the defaults that apply to Companion programming. For all other default settings, refer to *Norstar-PLUS Modular ICS 2.0 Installer Guide*.

Note: (U.S. only). Before registering Companion portable telephones you must first obtain and enter a certain number of portable credit keys. Also keep in mind, before the Base Stations can be recognized by the XC system, you must obtain and enter a UTAM Activation Key. Please refer to Software keys (U.S. only) on page 64 before setting up your wireless system.

Startup defaults

Setting	Default
Norstar DR 2.0 template	Square
Norstar XC 2.0 template	PBX
Start DN	221 (may be different for upgraded systems)

Passwords defaults

Reg. pswd*

Setting	PBX default	DID default
Reg. pswd	72346	

System prgrming defaults

Companion

Setting	PBX default	DID default
Registration Registration Portable DNs	N Available	defaults same as PBX
Radio data Re-evaluation Status Schedule Radio credits (U.S. only)	Required Not scheduled No defaults assigned	defaults same as PBX
Radios Cell Assignment Antenna Type	Unassigned Internal	
Cells Cell radio Cell nghbrs Cell rad nghbrs	Unassigned Unassigned Unassigned	
System LID	<random>	

Startup programming

After the hardware has been installed and powered up, use Startup to initialize the system, and select the system template that best suits your system.



Startup erases programming.

Startup erases any existing programmed data, and resets the system to factory defaults.

Performing Startup

1. Enter the Startup access code from a Norstar M7310 or M7324 telephone dial pad, by pressing

Feature	*	*	S	T	A	R	T	U	P	
Feature	*	*	7	8	2	7	8	8	7	.

which is the same as

To be accepted, the Startup code must be entered no later than 15 minutes after the Norstar system has been powered up. (If 15 minutes have elapsed since you powered up the system, turn system power off and on, to prepare for the Startup process.)

2. Enter the Installer password. The default is

C	O	N	F	I	G
---	---	---	---	---	---

 which is the same as

2	6	6	3	4	4
---	---	---	---	---	---

.



Tips - *The Installer password shown is the default normally used for Startup. For a system which has already been programmed, the Installer password might have been changed in programming and recorded in the Programming Record.*

Changing the default template

After entering the Startup access code and Installer password the display shows **Reset memory?**.

1. Press YES to select a default template. The display shows the current template.
2. Press CHANGE to choose the appropriate template.



Changing template resets programming.

If you change your system template, your programming will be reset.

Entering programming

After performing Startup, use programming to change default settings as required.

Headings and subheadings in programming help you to keep track of where you are.

Companion programming falls under System prgrming and has the following subheadings:

Registration	lets you enable and disable registration and verify which portable DNs are available
Radio data	lets you view and change cell and radio settings

For other programming operations refer to *Norstar-PLUS Modular ICS 2.0 Installer Guide*.

Entering programming for installers

1. Press * * 2 6 6 3 4 4 which is the same as * * C O N F I G . The display shows Password:.
2. Enter the Installer password. The default password is **CONFIG** (266344). The display shows **Terminals&Sets**. Three triangular indicators ► appear on the vertical display between the rows of buttons.
3. Place the programming overlay over the buttons pointed to by the indicators ►.

Entering programming for system coordinators

The person on staff who is in charge of making changes on the Norstar system is called the system coordinator. The everyday Companion programming done by system coordinators is described in *Norstar-Companion MICS-XC 2.0 System Coordinator Guide*.

Some system coordinators need to be able to program more advanced settings and functions in order to carry out the day-to-day requests and upkeep of the Norstar system. These coordinators are

usually dedicated communications specialists who work with large Norstar systems or other telephone systems like PBX or Centrex.

By using a special password, a system coordinator can see and change many, but not all, of the programming settings used by an installer. In this guide, programming that can only be changed by an installer is marked in the heading. If you are programming using the System Coordinator Plus password, you will not see these items when you move through programming.

1. Press * * 2 6 6 3 4 4 which is the same as * * C O N F I G . The display shows **Password:.**
2. Enter the System Coordinator Plus password. The default password is **SCPLUS** (727587). The display shows **Terminals&Sets**. Three triangular indicators ► appear on the vertical display between the rows of buttons.
3. Place the programming overlay over the buttons pointed to by the indicators ►.

Entering programming using other passwords

A set of the most often used headings and subheadings is available by using a System Coordinator password. This level of access is designed for the average user who takes care of the day-to-day changes to the Norstar system, but who does not need to use more advanced programming. The default password is **ADMIN** (23646).

Norstar features

Refer to *Norstar Companion MICS-XC 2.0 System Coordinator Guide* for a complete list of features supported on Companion portables.

Portable features

Refer to the *Portable Telephone User Guide* that comes with your portable.

External paging system (customer supplied)



Tip - *The external paging feature is supported on the Companion portable telephone. For more information on paging with a Norstar supported portable telephone, see Norstar-PLUS Modular ICS 2.0 Installer Guide.*

Registration password

Before anyone can begin making portable telephone calls, the portable telephones must be registered for use with the Norstar system. The recommended steps are as follows:

1. Change the registration password for your system.
2. Enable registration for the system.
3. Confirm the availability of directory numbers (DNs) for each Companion portable telephone.
4. Individually register each Companion portable telephone.
5. Disable registration for the system.

Changing the Registration password

To ensure unauthorized portables are not registered to your system, a separate level of password access is provided. You can, and should, set your own password to prevent unauthorized handsets from registering on your system. You can change the Registration password in Passwords.



Change password to avoid incorrect registration.

To ensure accurate registration, you should change the Registration password before registering any portables. If there is another wireless system in radio range, and both systems have the same Registration password and registration enabled, you may accidentally register on the other system instead of on your own.

The default Registration password is **RADIO** (7 2 3 4 6).

Use CHANGE, the dial pad and OK to program the Registration password.

Record the password in the Programming Record.



Tips - *You can choose any combination of one to six digits. It is easier to remember the password if the digits spell a word. Provide this password only to selected personnel to prevent unauthorized access to programming. The implications of such access may include the rearrangement of line assignments, which could affect the operation of the Norstar system.*

Companion programming

Companion programming is found under the System programming heading. It includes the following subheadings:

Registration



Software Keys are required to activate wireless capabilities (U.S. only).

To take advantage of the wireless capabilities available to your Norstar system, you must first enable a certain number of portable credits using Software Keys purchased through Northern Telecom. Keys are obtained and entered into the system by the installer. For more detailed information on enabling Norstar Companion, refer to the Software keys (U.S. only) on page 64.

You must enable registration for the entire Norstar system to allow individual portables to register. The options are Yes (Y) and No (N). Yes indicates that Registration is enabled. No is the default and indicates that Registration is not enabled.

Use and CHANGE to enable or disable registration. Press CREDITS (U.S. only) to view the credits available.



Registration should normally be disabled.

For security reasons, and to prevent unauthorized users from being registered to your system, set registration to N when you have finished registering the portables.

Portable DNs

Once registration is enabled for your Norstar Companion system, a series of extension numbers (637 to 666) automatically becomes available for registration. It is a good idea to check that an extension number is still available before registering a portable telephone to it.

If the extension number shows a status of Available, that extension number is ready for registering a Companion portable telephone.

If the extension number shows a status of Registered, a Companion portable telephone is already registered to that extension number. In this case, you can either pick a different extension number, or deregister the current portable telephone. You must perform deregistration at the portable and in either an Installer or System Coordinator programming session.

Press to view registered and available DNs.

Note: The DN range 637 to 696 can be used by either portable telephones or ISDN S-loops. You can assign all 60 of the DNs to S-loops and none to portable telephones. You can assign up to 30 DNs to portable telephones, leaving 30 for S-loops. Within these two limits you can choose a combination of ISDN and portable telephone DNs. For more information, refer to *Norstar-PLUS Modular ICS 2.0 Installer Guide*.

Deregistering a portable

Deregister an extension number when:

- the portable must be replaced due to loss or breakage
- the portable's owner departs and you want to assign the handset to someone else with a different telephone number

Press and DEREG to deregister a DN.



Tip - *This procedure does not clear the registration data in the portable. You must also deregister from the portable telephone ("on-the-air" deregistration). For instructions, see the Companion Portable Telephone User Guide that came with the portable.*

Radio data

Note: (U.S. only). Before registering Companion portable telephones you must first obtain and enter a certain number of portable credit keys. Also, before the Base Stations can be recognized by the MICS-XC 2.0 system, you must obtain and enter a UTAM Activation Key. Please refer to Software keys (U.S. only) on page 64 of this document before setting up your wireless system.

Re-evaluation

Re-evaluation will automatically assign the proper cell configuration to each radio in a Base Station. When adding or removing Base Stations, Re-evaluation needs to be applied to the system.



Schedule re-evaluation during least busy call times.

Plan on conducting a re-evaluation of your Norstar Companion when the system is not busy with calls. Wireless calls may be lost during the re-evaluation process.

After installing Norstar Companion components and obtaining the proper number of UTAM activation keys (see Software Keys), you need to verify that wireless re-evaluation has occurred. Alarm code messages *can* be used to indicate whether or not wireless re-evaluation has occurred:

Alarm	Definition	Re-eval occurred?
21	Re-eval in progress	No
22	Re-eval complete	Yes
23	Cell configured. Failed to come on line	No

Please refer to the *Alarm and Event Code Manual* for more information on alarm messages and the actions that should be taken to resolve any problems.

Re-evaluation Status

Press to see the Re-evaluation status. If the display reads **required**, you can carry out the re-evaluation by pressing **CONTINUE** and following the prompts.

Re-evaluation Schedule

This setting allows you to select whether you will proceed or schedule the next Re-evaluation.

The default setting is **Not scheduled**. If you wish to schedule a re-evaluation, press **CHANGE**. You can begin re-evaluation by pressing **NOW**, or schedule re-evaluation by pressing **LATER**. You will be prompted to enter a time and date.

Radios

Radio programming settings apply to Base Stations.

Radio credits (U.S. only)

Press **CREDIT** to see the number of radio credits available and the total number of radio credits. Verify that the total number of radio credits is enough to support the system you have just installed. The number of radio credits must be double the number of Base Stations you have installed. If the total number of radio credits is not enough for the system, you may need to obtain additional credits. See "Software keys (U.S. only)" on page 64.

Cell Assignment

A cell is the area covered by one or more radios in close proximity. As you move around your office, while on a call with your portable, the call is handed off from one cell to another. A call on a portable can be handed off from one cell to another only if those cells are programmed as neighbors. The Norstar system automatically assigns cell neighbors and re-evaluates the cell-to-cell configuration when Base Stations are added or removed.

This setting allows you to see if a Base Station radio is assigned to a cell in the Companion system.

Press and enter the radio number to see the radio setting: Assigned or **Unassigned**.

Antenna Type

Installer password required

This setting allows you to select the type of antenna to use for each Base Station in a system.

Press and enter the 5-digit radio number.

Use CHANGE to select the appropriate setting: **Internal** or **External**.

Cells

Cell programming allows you to examine the cell radio and cell neighbor configuration. Choose the cell you want to examine by pressing and the cell number (01 to 32).

Cell radios

This sub-heading allows you to view the 5-digit number of any radios assigned to this cell.

For example, if radio 07012 is in the cell, the display shows **07012 assigned**. Press and enter the 5-digit radio number to view the setting: **Assigned** or **Unassigned**.

Cell neighbors

This sub-heading allows you to view the 2-digit number of any cells that border a particular cell in a system. You can then remove any of them or add more cells. Press and enter the cell number to see the settings: **Assigned** or **Unassigned**.

For example cell 01, the display shows **Nghbr:03** and **Nghbr:04**. This means that cells 03 and 04 have been assigned as cell neighbors.

Cell rad neighbors

This sub-heading allows you to view the 2-digit number of any cells that border a particular cell in a system (the cell neighbors) plus any cells that border the cell neighbors. Press and enter the cell number to see the settings: **Assigned** or **Unassigned**.

For example cell 01, the display shows **Rad nghbr:03**, **Rad nghbr:04**, and **Rad nghbr:11**. Cell 11 does not appear as a cell neighbor (see the example under **Cell neighbors**), so it must be a neighbor of cell 03 or 04.

System logical identifier (LID)

Installer password required

This setting allows you to change the code by which the system identifies itself to portables and which the portables use to request service from the system. The default setting is randomly generated by the system at start-up. When the system logical identifier (LID) is changed, all portables must register again.

When changing the system LID, you can enter any hexadecimal number between 0500 and FFFE. (Hexadecimal characters can only range from 0 to 9 and A to E.)



Changing system LID de-registers all portables.

If you change the system LID, you will invalidate the registration of all the portables in the system. Portables will have to be re-registered before they can be used.

There are only two reasons to modify the system LID.

- The site has multiple systems, and you want users to be able to move from system to system without changing slots on their portable telephones. All systems must be set to the same system LID.
- Two systems that are located near each other were accidentally assigned the same system LID. Users of one system can access the other system. (This highly unlikely situation could occur, for example, in an office building occupied by multiple organizations.)

Use and CHANGE to modify the System LID.

Software keys (U.S. only)

The United States FCC has appointed UTAM Inc. as the body responsible for coordinating and verifying the installation or relocation of unlicensed, personal wireless communication devices. To comply with UTAM Inc., Norstar uses keys and credits to control user capacity and to ensure system location verification. These software keys and credits are required to activate Norstar Companion services on a new or upgraded system. The credits *should* have been purchased at the time the order was placed.



Base Station must be installed and powered first.

Base Stations must be installed and powered before entering any UTAM Activation Keys. Verify that the Base Station LED status is solid red and green before entering any UTAM keys. Failure to follow the correct order of UTAM key entry may result in a disabled Norstar Companion system.



Call Northern Telecom Customer Response Center at 1-800-321-2649 to verify that you have approval from UTAM Inc. when initially installing wireless equipment or relocating wireless equipment.

Failure to receive approval prevents you from enabling wireless communication on the Companion system. You will need to provide the Companion ID each time you are requesting codes or credits.

A disabled wireless system means that Base Stations and portables are not operational, but registration information is retained. These devices may be reactivated by returning the system to its previous configuration or by entering a UTAM Recovery Key. A new system is activated by entering a UTAM Activation Key.

The keys can be obtained and entered using the following steps.

Step 1: Obtain the Companion ID

The Companion ID Label is sent to each customer once radio credits have been purchased. In order to implement the credits and take advantage of the Norstar Companion capability, you need to obtain two sets of keys. One is the Credit Key and the other is the UTAM Activation Key. The keys are available by calling the Nortel Customer Response Center. You will need to provide the following information as shown on the Companion ID label:

- your Companion ID number
- the zip code
- the number of radio credits already purchased (if applicable)

Step 2: Obtain the System Identification Number

Obtain the System ID (SysID) by pressing

Feature * S Y S I D , or Feature * 7 9 7 4 3
on any M7324 or M7310 telephone display.

This information is also available by accessing **Software keys** in an Installer programming session:

1. Place the programming overlay on an M7310 or M7324 telephone.
2. Press Feature * C O N F I G . The display reads **Password:**.
3. Enter the most recent Installer password. The display reads **Terminals&Sets**.
4. Press Next until the display reads **Software keys**.
5. Press Show The display reads **SysID:** followed by the unique System Identification Number.
6. Press Next to continue in **Software keys** or Rls to exit.

Record the Companion ID and the SysID in the *Norstar MICS-XC 2.0 Programming Record*.

Step 3: Call the Nortel Customer Response Center

1. To obtain your two sets of keys call the Nortel Customer Response Center at: **1-800-321-2649**.

2. Follow the voice prompts for Norstar products. When you are asked for the information concerning your request, provide the following:
 - the Companion ID (on the label);
 - the customer's zip code (on the label); and
 - the System ID (see Step 1).
3. Indicate the number of radio credits you require. You will need two credits for every Base Station in your system.
4. You will be given two keys, the UTAM Activation Key and the Credit Key. The keys consist of three separate numeric strings that contain eight digits each.

UTAM Activation Key

This key activates wireless capability for a new system or a system upgrade which involves Base Stations. The software recognizes Base Station radios as **Radio credits**. There are two radios for each Norstar Companion Base Station. See **Radio credits (U.S. only)** on page 61 for information on viewing the available number of radio credits.

Portable Credit Key

This key predefines the maximum number of portables that can be registered to the system. Systems can only register as many portables as there are available Portable Credits. A maximum of 60 Companion portable telephones may be registered.



Record your keys in the Programming Record.

In the case of an upgrade, you will receive new keys. You will need the old and new keys to re-activate the system following a system restart.

Step 4: Enter the keys

You may enter the keys in either order: UTAM Activation Key first or Credit Key first. Keys are entered by first accessing **Software keys** in a programming session.

1. Press . The display reads **SysID:**.

2. Press . The display reads **Password keys**.
3. Press . The display reads **Key 1:**.
4. Enter the 8 digit password number for Key 1. Use **BKSP** to make corrections. The display reads **Key 2:**.
5. Enter the 8 digit password number for Key 2. Proceed as above until you have finished entering Key 3. The display reads **Entry successful**.
6. Repeat steps 3 through 5 for the other key.
7. Press until the display reads **Software keys** or to exit.

The system will now automatically start reevaluation and the display will show **Re-Eval in prog.**, **Re-Eval complete**, **System online**, as the reevaluation runs its course.

Note: If the UTAM Activation Code entry is unsuccessful, the display shows **Invalid code**. If this happens, reenter the code or call Nortel Customer Response Center at **1-800-321-2649** for assistance.

Step 5: Configure Base Stations and portables

Once you have entered the required keys to activate the Base Stations and to obtain enough portable credits, you can proceed with programming these items with the MICS-XC 2.0 system.

Configure your Base Stations

Companion Base Stations are recognized by the MICS-XC 2.0 system once the UTAM activation keys have been entered. To verify whether or not the Base Stations have been properly recognized, see Radio data on page 60 for information on the re-eval process.

Register your Companion portables

Norstar Companion Portable telephones are added to the system using the portable registration process. Refer to the *Norstar-*

Companion MICS-XC 2.0 System Coordinator Guide for more information on registering Companion portables.



Tip - *In the event your system has been powered down for an extended period of time, you need to contact the Northern Customer Response Center to obtain a UTAM Regression Key.*

If your Norstar Companion system seems disabled (all keys were input but Base Stations and portables are not operational), you need to contact the Northern Customer Response Center to obtain a UTAM Recovery Key.

Registering individual portables

Registering the C3050

The following section describes the procedures involved in registering Companion C3050 portable telephones. To register each portable with the Norstar system, you must do two things:

- Register the portables by entering the Registration password on each one.
- Verify that the portable functions correctly.

C3050 Icons

Some C3050 portable telephone icons for Canada and the United States are different but have the same functions. The following table identifies these icons:

C3050 Canada	Icon function	C3050 US
	Mute button	
	Hang up button	
	Answer button	
	Feature button	
	Telephone directory button	

To register the C3050

1. Turn on registration for your system.
2. Open the portable flap. The portable displays the current system name or **No system selected** for two seconds.
3. Press **[System]**. The portable displays **WIRELESS SYSTEMS**. Your portable can be registered to a maximum of nine different systems.
4. Press the **ADD** key to establish a radio link. The portable displays **Adding SYSTEM:#** for two seconds, then it displays **Pswd:**. If a radio link is not established, the portable displays

No connection. Close the flap, and repeat the procedure from step 1.

5. Enter the Registration password. The default is

7PQRS	2ABC	3DEF	4GHI	6MNO
-------	------	------	------	------

 (RADIO). The portable displays **DN:**. If the registration password is not correct, the portable displays **InvalidPswd**. Close the flap and repeat the procedure from step 1.
6. Enter the DN (between 637 and 666). The portable displays **Enter name**. If the DN is incorrect, the portable displays **Invalid DN**. If the registration fails, the portable displays **Reg failed**. If you try to register the C3050 to the same system twice, the portable displays the registered name, for example **Registered as NORTEL 1**.
7. Enter the system name (up to 16 characters), for example **NORTEL 1**. (If you are registering to only one system, use the portable telephone user's name.)

Press the key that has the letter. For example, to enter A, press

2ABC

, to enter B, press

2ABC

2ABC

.

Press SPACE to add a blank space to the name.

Press BKSP to remove a mistake.

Press ◀ or ▶ to move the cursor backward or forward.

8. Press SAVE. The portable displays the registered name, for example **NORTEL 1 registered**.
9. Turn off registration for your system.

To confirm that the C3050 is registered

1. Close, then open the portable flap.

If the portable displays the system name that you just registered, proceed to step 5.

If the portable displays a different system name, or **No system selected**, proceed to step 2.

2. Press System. The portable displays **WIRELESS SYSTEMS**.

3. Press the scroll keys ( or ) until the system name is displayed.
4. Press **SELECT** (or **OK** if the correct system is already selected).
5. Press  or . You hear a dial tone, and the portable displays .

If you do not hear a dial tone, check that you have selected the correct system and try to register the portable again.

6. Close the portable's flap, and set the Ringer Control Switch to .

If the portable is twinned with a desk telephone, make sure the desk telephone is idle and Call Forward is not active.

7. On another working telephone, dial the telephone number of the registered portable. If the portable rings, it is functioning properly.

If you do not hear a dial tone, or if the portable does not ring, refer to the Troubleshooting section in this guide. If you still cannot register the portable, contact your system supplier.

Deregistering the C3050

You can deregister the C3050 in two ways:

- from the portable
- from the administration set

You can deregister the portable to clear information stored in the portable and the system. To do this, you must be within the coverage area. For example, you may want to deregister the portable before you assign it to another DN.

You can also deregister a portable using the Norstar administration set. You could use this method if the portable was lost or stolen, or if you wanted to assign it to another system. This procedure does not clear registration data from the portable.

If the portable is registered on other systems, it will still be available on those systems. You deregister from one system at a time.

To deregister the C3050

1. Open the portable's flap.
2. Press **System**. The portable displays **WIRELESS SYSTEMS** and **ADD**.
Note: Do not select **ADD**.
3. Press the scroll keys (∇ or $\triangle$) to display the system name that you want to deregister.
4. Press **ERASE**. The portable displays **Erase item?**.
5. Press **OK**. The portable displays **Deregistering...** and then **Item erased**.

Measuring RSSI for a C3050

The Receive Signal Strength Indicator (RSSI) is a measurement of the signal strength the Base Station receives from the portable. The Base Station controls the power transmitting mode of the portable. When the Base Station receives a weak signal, it instructs the portable to transmit in high-power. When the Base Station receives a strong signal, it instructs the portable to transmit in low-power. The strongest RSSI value the portable displays is -45 dBm (in the US) and -44 dBm (in Canada). The weakest RSSI value the portable displays is approximately -94 to -100 dBm.

To measure undirected RSSI

You can measure the signal strength between a portable and a system-selected Base Station radio using undirected RSSI.

1. Open the portable flap.
2. Press **Line** or .
3. Press  **8TUV** **9WXY2** **8TUV**. The portable displays the radio ID of the Base Station that the portable is linked to, followed by the signal strength and the power mode, for example **03142 - 54 H**. Hand-off occurs normally between the cell boundaries.

In this example, the module is **03**, the port is **14**, and the radio is **2**. The signal strength measured by the Base Station is -54 dBm, and the **H** indicates that the portable is transmitting in high-power mode (an **L** indicates low-power mode).

4. To end the connection, press **End** or  or close the flap.

Measuring directed RSSI

You may want to measure the RSSI between a portable and a specific Base Station radio. For example, you may suspect that one of the two radios in a Base Station is not working properly. You can also use directed RSSI to prevent hand-off while you find a cell edge. To measure the RSSI of a specific radio, you must be in range of two Base Stations—the one you want to measure and another Base Station.

You cannot measure the directed RSSI of both radios in the Base Station at the same time.

Before you begin to measure directed RSSI

Use the *Companion Provisioning Record* to find the following:

- The five-digit ID of the Base Station radio you want to measure, by mapping the Base Station location to the time compression multiplex (TCM) port. The first four digits indicate the TCM port to which the Base Station is connected. The last digit indicates the number of the radio on the Base Station. For example, the number 03142 on the Base Station is connected to TCM port 0314, and 2 is the radio number. The five-digit number may be printed on a label affixed to the lower right corner of the Base Station mounting bracket.
- The radio IDs of all other Base Stations in the same location.

To measure directed RSSI using your portable

1. Repeat steps 1 to 3 of "To measure undirected RSSI".
2. When the portable displays the Base Station ID you want to measure, move out of the cell boundary range so that hand-off occurs, and press **End** or .
3. Press **Line** or .
4. Press  **8**^{TUV} **9**^{WXYZ} **9**^{WXYZ}.
5. Enter the five-digit ID code for the Base Station radio you want to measure. The portable displays this ID followed by the signal strength and the power mode, for example 03142 - 54 H. Hand-off does not occur as you move between the cell boundaries. The link drops when you move out of range.

In this example, the module is 03, the port is 14, and the radio is 2. The signal strength measured by the Base Station is -54 dBm, and the H indicates the portable is transmitting in high-power mode (an L indicates low-power mode).

6. To end the connection, press **End**,  or close the flap.

Registering the C3020 (Canada only)

The following section describes the procedures involved in registering Companion C3020 portable telephones. To register each portable with the Norstar system, you must do two things:

- Register the portables by entering the Registration password on each one.
- Verify that the portable functions properly.

To register the C3020

1. On the Administration set, turn on registration in a general programming session. See "Companion programming is found under the System programming heading. It includes the following subheadings:" on page 58.
2. On the portable, press **Shift**, then press **Memory**.
3. Press **Office**.
4. Check the portable's display.

If the portable has space for another system, the display shows **Office n: Free**.

If the display does not show **Office n: Free**, follow the procedures in "Deregistering the C3020" to overwrite the system number then return to step 2 of this procedure.

5. Press **Shift**, then press **Memory**. The display shows **Registering...**
6. Next, enter the Registration password when the display shows **Pswd:**. The default is **7PRS 2ABC 3DEF 4GHI 6MNO (RADIO)**.

If the display does not clear after entering the password, then you may be using the wrong password.

7. Wait for the display to clear. When it shows DN#, enter the internal number (637-666) you want to assign to the portable. When the display clears, it shows Reg'n complete.
8. On the administration set, turn off registration in general programming, Companion, subheading Registration. See "Companion programming" on page 58.

To confirm that the C3020 is registered

1. To check that the portable has a dial tone, press Line.

If you hear a dial tone, go to step 2.

If you do not hear a dial tone, check that you have selected the correct system number and press Line again. If you do not hear dial tone try to register the portable again.

2. Make sure that the flap is closed and the Ringer Control Switch is in the bottom position. Make sure the portable telephone is idle and call forward is not active.
3. On a working telephone, dial the telephone number of the registered portable.

If the portable rings, it is functioning properly.

If the portable does not ring, try to register the portable again.

If you do not hear a dial tone, or if the portable does not ring, refer to the Troubleshooting section in this guide.

Deregistering the C3020 (Canada only)

You can deregister the C3020 in two steps:

- from the portable
- from the administration set (For more information about using the Norstar administration set, see the *Norstar-PLUS Modular ICS 2.0 System Coordinator Guide*.)

For example, you may want to deregister the portable before you assign it another number on the same system.

You can also deregister a portable using the administration set. You could use this method if the portable was lost or stolen or if you

wanted to assign it to another system. This procedure does not clear registration data from the portable.

If the portable is registered on other systems, it will still be available on those systems. You deregister one system at a time.

To deregister the C3020

1. Press **(Shift)**, then press **(Memory)**.
2. Press **(Office)**. The display shows Office n:.
3. Press either **(Shift)** then **(#)**, or **(Shift)** then **(*)** until you display the system you want to deregister.
4. Press **(Shift)**, then press **(0)**. The display shows Deregister?.
5. Press **(Shift)**, then press **(0)** again. The display shows Deregistering... and then Deregistered.
6. To continue using the portable, press **(Release)**.

Measuring RSSI for a C3020 (Canada only)

The Receive Signal Strength Indicator (RSSI) is a measurement of the signal strength the Base Station receives from the portable. The Base Station controls the power transmitting mode of the portable. When the Base Station receives a weak signal, it instructs the portable to transmit in high-power. When the Base Station receives a strong signal, it instructs the portable to transmit in low-power. The strongest RSSI value the portable displays is -44 dBm. The weakest RSSI value the portable displays is approximately -85 to -95 dBm.



Receive Signal Strength Indicator overrides normal display.

You cannot receive calls while measuring Receive Signal Strength Indicator.

Measuring undirected RSSI

You may want to measure the Receive Signal Strength Indicator between a portable and a Base Station radio.

1. Press **(Line)**. Wait for dial tone.

2. Press **[*]**. Enter the feature code: **[8^{TUV}] [9^{WXY}] [8^{TUV}]**.

The display shows the radio ID of the Base Station to which the portable is linked, followed by the signal strength, for example 03121 – 67. In this example, the module is “03,” the port is “12,” and the radio is “1.” The signal strength is “-67dBm.”

3. Read your measurement. Hand-off occurs normally.
4. To end the connection, press **[Release]** or close the flap.

Measuring directed RSSI

You may want to measure the Receive Signal Strength Indicator between a portable and a specific Base Station radio. For example, you may suspect that a radio in a Base Station is not working properly. You can also use directed Receive Signal Strength Indicator to prevent hand-off while you find a cell edge. To measure the Receive Signal Strength Indicator of a desired radio, you must be in range of two Base Stations—the one you want to measure, and another Base Station.



Receive Signal Strength Indicator applies to one radio in a Base Station.

You cannot measure the directed Receive Signal Strength Indicator of the other radio in the Base Station to which you are connected.

Before you begin measuring directed RSSI

Use the *Companion Provisioning Record* to find and note the following:

- The five-digit radio ID of the Base Station you want to measure, by mapping the Base Station location to the TCM port. The first four digits indicate the TCM port to which the Base Station is connected. The last digit indicates the number of the radio on the Base Station. For example, the number “03122” identifies radio “2” on the Base Station connected to TCM port “0312”.
- The radio IDs of all other Base Stations in the same location.

Measuring directed RSSI using your portable

1. Perform an undirected Receive Signal Strength Indicator by following steps 1 to 3 in “To measure undirected Receive Signal

Strength Indicator.” To direct the Receive Signal Strength Indicator to the other radio of the Base Station, move out of range until hand-off occurs before moving on to step 2.

2. Press **Line**. Wait for dial tone.
3. Press ***** **8^{TUV}** **9^{WXY}** **9^{WXY}**.
4. Enter the five-digit ID code for the Base Station radio you want to measure. The display shows this ID followed by the signal strength, for example 03121 – 67. If you have not established a connection with the desired Base Station radio, you hear a tone when you hold the portable to your ear.
5. Read your measurement. The system will drop the link when you move out of range of your Base Station (no hand-off).
6. To end the connection, press **Release**, or close the flap.

After registering the portables

When you have completed programming the system, use the following checklist to ensure you completed the required tasks.

- ☐ Register the portables.
- ☐ Verify Portable Credits.
- ☐ Ensure that you registered all the required portables.
- ☐ Verify that all portables are available for use.
- ☐ Test each portable to verify it is operating properly.
- ☐ Disable Master Registration when you have finished registering the portables.

For the steps involved in operating a Norstar Companion portable, see *Companion Portable Telephone User Guide* that came with the portable.

When you distribute the portables, tell the users that the portables are registered and give them the corresponding extension numbers.



Tip - *You can register a portable to more than one system. You cannot register a portable to more than one extension number per system. You cannot register more than one portable to one extension number.*

If a portable telephone will be used in more than one Norstar or Companion system, its owner must know which registration slot number was used to register the portable telephone with each system. (It is preferable that each user register the system they use most in slot 1.)

If a portable telephone is lost or broken, you can deregister it from the system before replacing it with another portable telephone.

Testing

Testing the Companion portable telephones

You must register all portable telephones before testing them. For more detail on registering portable telephones, refer to *Norstar-Companion MICS-XC 2.0 System Coordinator Guide* and the Telephone Registration Instructions.

1. Verify that the portable telephone is ON.
2. Establish a connection to get internal dial tone. If no dial tone is present, the portable telephone may not be registered. Try to register the portable telephone again.
3. Verify that the portable telephone is using the correct registration slot.
4. Verify that the portable telephone can make a call.
5. Verify that the portable telephone has been assigned the correct extension number by calling a wired telephone and viewing the line number displayed.



Tip - *Automatic Telephone Relocation will not retain programming when moving a Companion Base Station from one port to another.*

Testing the Base Stations

1. Verify that the ICS is ON.
2. Verify that re-evaluation is complete.
3. Verify that the Base Station has been powered up correctly by checking that the green light is ON and the red light is OFF.

If the red light is flashing, it indicates that one of the following problems may exist:

- The Base Station is not connected to the ICS.
- The Base Station is faulty and should be replaced.

A solid red light indicates that both radios on the Base Station are busy, that the ICS is downloading data to the Base Stations, or that one or both radios have not been assigned to a cell.

4. Using the directed Received Signal Strength Indication (RSSI) feature on a portable telephone verify that you can establish a link with every radio on the system while within the cell range of the radio. Using another portable, establish a second link with the other radio on the same Base Station and check that the red light is ON while both radios are active.

Testing the system coverage

Using the undirected Received Signal Strength Indication feature on a portable telephone, verify that the Base Stations are handing off calls and serving the coverage area as intended. To check valid handoff, move from one cell to another. As you do this the radio number shown on the portable telephone display changes.

To test system coverage at critical points, follow these steps:

1. Make a call. Move over the entire coverage area (including stairs, elevators and critical points) while maintaining the call on the portable. You should maintain good quality speech throughout the area you are moving in.
2. Check that you can receive a call while at these critical points. If a significant hole in the coverage area is found and the Base Stations are working properly according to the above tests, refer to *Companion Site Planning Guide*. You may need to re-deploy the Base Stations or add an additional cell.

Troubleshooting

Problems with a portable telephone

1. Verify that the portable is compatible with the software version.
2. Verify that the portable is ON and that the battery is not low, by checking the power indicator on the portable.
3. If no dial tone is present:
 - a. Verify that the dialtone is available from the ICS.
 - b. The portable may not be registered. Try to register the portable (see *Norstar-Companion MICS-XC 2.0 System Coordinator Guide*).
4. Check that the portable is using the correct registration slot.
5. Verify that the portable has been assigned the correct internal number by calling it from another telephone.

Problems with a Base Station

1. Verify that the green light is ON.
2. Verify that the red light is not solid.

A solid red light indicates that both radios on the Companion Base Station are busy, that the ICS is downloading data to the Base Stations, or that one or both radios have not been assigned to a cell.

3. Verify that the red light is not flashing.

The red light flashes for about 15 seconds when a Base Station is powered up. This is normal. If the red light continues to flash, it indicates that one of the following problems may exist:

- The ICS or Station Module is not ON.
- The Base Station is not connected to the ICS or Station Module.
- The wiring to the Base Station is not correct.
- The TCM wiring length between the Base Station and the ICS (or Station Module) exceeds 1200 m.

- There is a faulty ICS, Station Module, or RPI.
 - The two-way DC loop resistance of the power pairs between the Remote Power Interconnect (RPI) and the Base Station exceeds 90 ohms. Measure the loop resistance with an ohmmeter. If the resistance exceeds 90 ohms, install a second power pair, or power the Base Station with a plug-top power supply.
 - The Base Station is faulty.
4. Verify that the power cord of the RPI is properly connected to a working AC outlet. If the Base Station is powered locally, verify that the power supply is properly connected to a working AC outlet and that the power supply cable is properly connected to the Base Station power connector
 5. If an external antenna is installed, verify that the external antenna coaxial cable is properly connected to the BNC connector of the Base Station and that the corresponding radio is programmed to have an external antenna (see Installing external antennas and lightning surge arrestors on page 34).

Note: Ensure there are not any bridge taps on the TCM.

Replacing a Base Station

To replace a Base Station, you do not have to power down the ICS. When you replace a Base Station, no portable registration information is lost. After a short boot sequence, the Base Station should be functioning normally.



(U.S. only) If you are relocating a Base Station, call the Northern Telecom Customer Response Center at **1-800-321-2649** to verify that you have approval from UTAM Inc. (Please have your System ID number ready when you call.)

Taking a Base Station out of service causes radio coverage to degrade.

To replace a Base Station, follow these steps:

1. If the Base Station is powered locally, unplug the power supply from the AC outlet and unplug the power supply connector from the Base Station
2. Remove the cover from the Base Station.
3. If an external antenna is installed, unplug its coaxial cable from the Base Station.
4. Unplug the teledapt cable from the Base Station.
5. While holding the Base Station (to prevent it from falling), apply upward pressure to the Base Station.
6. Lift the Base Station away from the bracket.
7. Carefully install the new Base Station onto the bracket.
8. Gently press down to snap it into position.
9. Reconnect the teledapt cable to the Base Station connector.
10. Reconnect the power supply connector and external antenna coaxial cable to the connectors from which they were removed.
11. If the Base Station is powered locally, plug the power supply into the AC outlet.

The red light on each Base Station will flash for about 15 seconds while powering up. This is normal.

Verifying Radio Credits (U.S. only)

You will need the programming template found at the front of the *Norstar-PLUS Modular ICS 2.0 System Coordinator Guide*.

1. Press * * 2 6 6 3 4 4
(* * C O N F I G).
2. Press (the default Installer password).
3. Press until you reach **System Prgrming**.
4. Press once.
5. Press until you see **Companion**.
6. Press . The display shows **Registration**.
7. Press until the display shows **Radio credits**.
8. Press once. The display shows **nnn Available**.
Press . and the display shows **nnn Total** . Verify that the total number of Radio Credits is enough to support the system you have just installed.

Note: The number of Radio Credits must be double the number of Base Stations you have installed. Each Base Station has two radios so each Base Station requires two credits.

Note: As each Base Station is initialized the number of available Radio Credits will decrease accordingly.

Problems with an RPI

To troubleshoot an RPI, follow these steps:

1. Verify that the RPI is plugged into a working AC outlet.
2. Verify that all the connections (power cord, jumper lead, input and output, and so on) to the RPI are correct and secured.
3. Verify the power supply:
 - Verify the power cord fuse.
 - Verify the green internal RPI light is on.
 - Verify the Base Station's green light is on.

- Verify that the red light is not solid. A solid red light indicates that both radios on the Base Station are busy, that the ICS is downloading data into the Base Stations, or that one or both radios have not been assigned to a cell.
 - Verify that the red light is not flashing. The red light flashes for about 15 seconds when a Base Station is powered up. This is normal.
4. If none of the Base Stations connected to the RPI (or to one of its power supply units) is functioning correctly, replace the RPI (or power supply unit).



Tip - *The left power supply unit provides power through output connectors OK1 to OK8 or OBIX1 to OBIX8, and the right power supply unit provides power through OK9 to OK16 or OBIX9 to OBIX16.*

If only one or a few of the Base Stations seem faulty, see Problems with a Base Station.

Problems with wireless communication

Obtaining a Recovery Key (U.S. only)

A disabled Norstar Companion system implies that Base Stations and portables are not operational. UTAM registering information is, however, retained.

To reactivate Norstar Companion communication on a disabled system, you require a UTAM Recovery Key. To obtain and enter the Recovery Key, follow the procedures for the UTAM Activation Key explained in Software keys (U.S. only) on page 64.

Obtaining a Regression Key (U.S. only)

You may need a Regression Key if one of the following conditions occurs:

- a defective ICS is replaced
- an ICS has lost its System Identification Number (SysID) due to a power outage for more than 72 hours

If you need a Regression Key, follow these steps:

1. Record the new System Identification Number once the system is powered up. See Step 2: Obtain the System Identification Number on page 65 for more information.
2. Locate the following information in the *Norstar-PLUS MICS-XC 2.0 Programming Record*.
 - the original SysID
 - all previously entered radio and portable credit keys
3. Call Northern Telecom Customer Response Center at **1-800-321-2649** to request a Regression Key.
4. Provide them with the original and new SysID, Companion ID, customer address and zip code. See Software keys (U.S. only) on page 64.
5. Make a note of the new Regression Key.

A Regression Key cannot be reused. Please do not record this Key in the *Programming Record*.

6. Enter the Regression Key. Follow the same procedure for entering software keys on page 64.

Once the keys have been entered, the previous SysID is restored.

7. Re-enter all radio and portable credit keys recorded in *Norstar-PLUS MICS-XC 2.0 Programming Record*.
8. Verify that the correct number of Radio Credits is available (see Verifying Radio Credits (U.S. only) on page 86).
9. Re-enter all programming data using information from the *Programming Record*.
10. Reregister all portables.

Alarm codes

For a complete list of Norstar alarms, consult the *Norstar Alarm & Event Code Manual*. Also consult the *Norstar-PLUS Modular ICS 2.0 Installer Guide*.

Displays

Example display	Meaning	Possible causes and actions
Alarm: 21	Wireless re-evaluation in progress	Scheduled or required re-evaluation of wireless Base Stations in system
Alarm: 22	Wireless re-evaluation complete	Scheduled or required re-evaluation of wireless Base Stations in system
Alarm: 53	A single radio has been removed from service due to an error. An accompanying event message will indicate an explicit reason for the radio failure.	
Alarm: 54	A software download to the Base Stations has started.	
Alarm: 55	The Base Station download is complete.	
Alarm: 68	An upgrade has been performed.	A trunk or station module has been added to a system to which Base Stations are already connected. The Base Stations must be moved to the highest numbered ports on the system.
Alarm: 200	Insufficient radio credits	
Alarm: 201	Radio credits decreased	

Example display	Meaning	Possible causes and actions
Alarm: 202	UTAM key required	(U.S. only) Valid UTAM Activation Key required. See "Radio data" on page 60.
Alarm: 203	UTAM test failed	(U.S. only) System detected an incorrect configuration, possibly due to malfunctioning equipment.
Alarm: 204	Evaluation override is finished	
Alarm: 205	Disablement test active	
Alarm: 206	Disablement test is finished	
Alarm: 207	System startup	System initialization is beginning
Alarm: 208	System online	System initialization is finished
Alarm: 209	Demo system	
Re-Eval required	System Re-evaluation required	This message occurs when a new Base Station is added to the system or is moved to a different port. Run System Reevaluation immediately or schedule a System Reevaluation. See Re-evaluation on page 60.

Example display	Meaning	Possible causes and actions
Re-Eval recommended	System Re-evaluation recommended	Base Station may have lost power for longer than 3 minutes or was replaced with a new Base Station. You may - run System Reevaluation immediately - schedule System Reevaluation or - <u>CANCEL</u> to disregard message See Re-evaluation on page 60.
UTAM key req'd	System disabled	Common message for a new installation, see Software keys (U.S. only) on page 64. The only other time this alarm should appear is if you are rebuilding a system: 1. Enter a UTAM Activation Key. See Software keys (U.S. only) on page 64. 2. Obtain a Regression Key. See Obtaining a Regression Key (U.S. only) on page 87.

Example display	Meaning	Possible causes and actions
UTAM test failed	System is disabled. This alarm will appear only after a restart	- Ensure there is power to the Base Stations and RPI or plug-top power supply - Ensure that the location and number of Base Stations is correct - Ensure that there are at least four cells in the system configuration - Ensure that there are sufficient Radio Credits to support the number of Base Stations you have connected - Restart the system with the correct system configuration. -The system may require a UTAM Recovery Key. See Obtaining a Recovery Key (U.S. only) on page 87.

Example display	Meaning	Possible causes and actions
Radio cred req'd	Too many Base Stations have been connected to the system. This message will only appear after a restart.	Too many Base Stations have been connected and the total available Radio Credits are insufficient to accommodate all the radios. Wireless communication remains disabled. System Reevaluation may be disabled. 1. Verify the total and available number of radio credits. See Verifying Radio Credits (U.S. only) on page 86. 2. Remove the excess Base Stations and restart the system. To determine the number of connected Base Stations to remove, subtract the total number of radio credits from the total number of connected Base Stations. Remember that each Base Station has two radios. See Problems with an RPI on page 86. If you have increased the number of Base Stations you may need a new UTAM Activation Key to cover the increase in Radios. See Software keys (U.S. only) on page 64. If Radio Credits are required then reevaluation is disabled. See Re-evaluation on page 60.

Event messages

Event message display	Cause
Evt:275-3546 58	(U.S. only) Unable to activate all registered portables. The system ran out of portable credits. One event is generated per portable that failed to activate. The repetition of the corresponding alarm code 59 indicates how many additional credits must be purchased.
Evt:301-1031 55	The Base Station (on port 0103 in this case) cannot successfully receive the data image. Both radios belonging to the Base Station will be disabled. This may occur if the flash EEPROM is faulty. Two events are raised: one for the B1 channel radio (as in this case) and another for the B2 channel radio. A corresponding alarm code 53 will occur.
Evt:302-1031 55	The Base Station (on port 0103 in this case) cannot be written to during data transfer. Both radios belonging to the Base Station will be disabled. The Base Station's flash EEPROM is faulty. Two events are raised: one for the B1 channel radio (as in this case) and another for the B2 channel radio. A corresponding alarm code 53 will occur.
Evt:303-1031 5	The Base Station (on port 0103 in this case) cannot be synchronized with the other Base Stations in the system. Both radios belonging to the Base Station will be disabled. The Base Station hardware is faulty. Two events are raised: one for the B1 channel radio (as in this case) and another for the B2 channel radio. A corresponding alarm code 53 will occur.
Evt:304-01032	A B2 channel radio (radio 2 on port 0103 in this case) cannot be synchronized with other radios because of system overload.

Event message display	Cause
Evt:305-01032 S5	A B2 channel radio (radio 2 on port 0103 in this case) cannot be synchronized because the B1 radio was disabled in maintenance. Both radios belonging to the Base Station (on port 0103 in this case) will be disabled. The B1 radio must be operational to synchronize both radios of the Base Station with other radios in the system. Two events are raised: one for the B1 channel radio and another for the B2 channel radio. A corresponding alarm code 53 will occur.
Evt:306-01031 S5	A radio (0103-1 in this case) cannot be synchronized because there are no B2 channel radios. Both radios belonging to the Base Station (on port 0103 in this case) will be disabled. Two events are raised: one for the B1 channel radio in this case) and another for the B2 channel radio. A corresponding alarm code 53 will occur.
Evt:307-0109100 S5	A recoverable RIM fault has occurred The RIM will be reset. If a link is active when this error occurs, the link is dropped. The radio (0109-1 in this case) is returned to service.
Evt:307-0109101 S5	An unrecoverable RIM fault has occurred The radio (0109-1 in this case) will be disabled and taken out of service. If a link is active when this error occurs, the link is dropped. A corresponding alarm code 53 will occur.
Evt:307-0109102 S5	The built-in self-test on the Base Station has failed The radio (0109-1 in this case) will be disabled and taken out of service. If a link is active when this error occurs, the link is dropped. A corresponding alarm code 53 will occur.
Evt:308-0103 S8	The Base Station is connected to a system that supports a radio protocol that the ICS does not understand.
Evt:664 S8	There is a bad signature.
Evt:665 S4	(U.S. only) there are insufficient radio credits.

Event message display		Cause
Evt:666	S5	(U.S. only) radio credits decreased.
Evt:667	S5	(U.S. only) UTAM keys are required.
Evt:668	S5	(U.S. only) UTAM test failed.
Evt:669	S5	Evaluation override is finished.
Evt:670	S5	Disablement test is active.
Evt:671	S5	Disablement test is finished.
Evt:672	S5	System initialization is beginning.
Evt:673	S5	System initialization is finished.
Evt:675	S5	Demo system.
Evt:831	S5	Software error dealing with Base Station.
Evt:832	S5	System problem with locating portable telephones.
Evt:833	S5	The radio driver software which directly controls the Base Stations' device has experienced an internal error.
Evt:834	S5	System problem with locating portable telephones.
Evt:835	S5	Wireless system access error.
Evt:836	S5	Wireless system access error.
Evt:837	S5	Trying to register an incompatible wireless device.
Evt:840	S5	Wireless system software error in dealing with a portable telephone.

Event message display		Cause
Evt:841	S5	Wireless system software error.
Evt:842	S5	Portable does not support specific display character.
Evt:843	S5	Internal radio driver error.
Evt:848	S5	A cell manager has been unable to register with the router.
Evt:849	S5	Synchronization error.
Evt:850	S5	Synchronization error.
Evt:851	S5	Base Station software error.
Evt:852	S5	The Data Transfer server has been told by the Base Station that an error has occurred.
Evt:853	S5	The Data Transfer server has been told by the Base Station that an error has occurred.
Evt:854	S5	Invalid event for Data Transfer.
Evt:855	S5	Internal wireless subsystem software error.
Evt:856	S5	Internal wireless subsystem locator error.
Evt:859	S5	All possible wireless telephone numbers have been registered to portable telephones. No directory number is available to handle the registration Link setup request.
Evt:864	S5	A Base Station has received a corrupted stimulus message.
Evt:865	S5	The Base Station does not understand the received stimulus message. This occurs when you are trying to use a type of portable that the system does not support.
Evt:869	S5	Wireless subsystem language loading error.

Event message display		Cause
Evt:870	S5	Firmware downloading to Base Station.
Evt:871	S5	Basestation download is complete.
Evt:872	S5	Wireless subsystem error.
Evt:873	S5	Wireless subsystem Common Signaling Channel server software error.
Evt:877	S5	Wireless auto-admin (Re-Eval) subsystem detected that a data re-evaluation is required.
Evt:878	S5	Wireless data re-evaluation has started.
Evt:879	S5	Wireless data re-evaluation has completed.
Evt:881	S5	Wireless auto-admin (Re-Eval) indicating that a configured cell failed to come on-line. Alarm 23 will display cell that failed.
Evt:884	S5	The Wireless auto-admin (Re-Eval) subsystem has detected an error.
Evt:885	S5	Sequencer functionality has detected an error.
Evt:886	S5	The Wireless auto-admin (Re-Eval) Initial Intelligence component has detected an error.
Evt:887	S5	The Wireless auto-admin (Re-Eval) radio Sniffing component has detected an error.
Evt:888	S5	The Wireless auto-admin (Re-Eval) Radio Manager has detected an error.

Specifications

Norstar Companion system components

Remote Power Interconnect

The Remote Power Interconnect (RPI) device power lines are protected by 3 A, 250 V anti-surge fuses. Each output has short-circuit protection.

Part no.	In the US RPI-8: NTE018AA (A0627387) ^a RPI-16: NTE019AA (A0627397) ^b
	In Canada RPI-8: NTE002AA (A0402787) RPI-16: NTE003AA (A0402780)
Color	Dolphin Gray
Height	35.6 cm (14 in.)
Width	30.5 cm (12 in.)
Depth	7.6 cm (3 in.)
Input voltage	80 to 270 V AC
Input frequency	40 to 70 Hz
Output voltage	48 V DC
Output current	1.1 A
Operating temperature	0°C to 50°C (32°F to 122°F)

a. will be replaced with RPI-8 NTE023AA (A0667940)

b. will be replaced with RPI-16 NTE024AA (A0667941)

The length of the cord, from the outside surface of the unit to the plug, should be a minimum of 1.4 m (4.5 ft.) and a maximum of 4.2 m (15 ft.).

Base Station

The Base Station consists of two printed circuit boards: the Line Interface Module (LIM) and the Dual Radio Interface Module (RIM). The Base Station provides connectors for a terminating line cord, external antennas, and a power supply cord. Only passive antennas may be connected to the antenna sockets on the Base Station.

Part no.	NTAE20AA (A0401506 in the US) NT0P30DA-93 (A0403378 in Canada)
Color	Dolphin Gray
Height	20 cm (8 in.)
Width	32 cm (12 in.)
Depth	5 cm (2 in.)
Weight	less than 1 kg (less than 2 lbs)
Input voltage	12 to 50 V DC
Maximum loop length (TCM)	1143 m (4,000 ft.)
Operating temperature	5°C to 40°C (+32°F to +120°F)
Relative humidity	5 to 85% (condensation may occur)
Peak power rating	15 dBm

Base Station plug-top power supply

If a plug-top power supply is required, use only the power supply recommended for use with the Base Station. Other usage will invalidate any approval given to this apparatus.

Part no.	A0386334
Color	Dolphin Gray
AC supply voltage	120 V
AC supply frequency	60 Hz

Secondary voltage	12 V
Secondary current	800 mA
Operating temperature	5°C to 40°C (+32°F to +120°F)
Relative humidity	5 to 85% (condensation may occur)
Height	10 cm (4 in.)
Width	10 cm (4 in.)
Depth	6 cm (2 in.)

External antenna assembly (For the US)

Part no.	antenna: NTAE50AA (A0637293)
Frequency range	1.92 to 1.93 GHz
Peak power rating	+13.5 dBm
Peak antenna gain	between -1.2 and 1.5 dBi
Polarization	nominally vertical
Input impedance	50 Ω nominal
Voltage standing wave ratio	better than 1.5:1
Extension cable loss	below 4.5 dB
Lightning surge arrestor circuit current	3 kA
Lightning surge arrestor waveform pulse	$8_{/20}$ μ S
Lightning surge arrestor repetition	20 times

Outdoor omni-directional antenna (For Canada)

Part no.	A0383818
Frequency range	944 to 952 MHz
Peak power rating	10 mW minimum
Peak antenna gain	4 dBi maximum
Polarization	vertical
Input impedance	50 Ω nominal
Temperature	-50 °C to +55 °C
Humidity	0% to 100%
Length	49.0 cm maximum
Width	3.5 cm maximum
Weight	1.0 kg maximum

Lightning surge protector

Part no.	A0382082
Surge capability	50 000 A (repeatable)
Turn-on threshold	600 V dc
Turn-on time	2.5 ns
Impedance	50 ohms
Operating frequency range	125 MHz to 1 GHz

Upgrading your system

Adding Companion to a mini, midi, maxi, or mega system

On a mini system (non-expanded), only module 1 (ports 101 to 132) can be used for Companion Base Stations and/or wireline sets. Module 2 is used for trunk modules only.

On a midi system (2- port expansion) ensure that Station Modules 3, or 4, or both are available to connect Norstar sets or Base Stations. Base Stations cannot be connected to any other module.

On a maxi system (6-port expansion), ensure that the Station Modules 7, or 8, or both are available to connect Norstar sets or Base Stations. Base Stations cannot be connected to any other module.

On a mega (XC) system (12-port expansion), Station Modules 13 and 14 are reserved for Base Stations only.

Upgrading an RPI-8 to an RPI-16



Only distributors and authorized service personnel are permitted to upgrade an RPI-8.



Do not power up the RPI until the installation is complete. This includes the installation of Base Station cross-connectors.


If you are adding extra lines for Base Stations, always power down the RPI before you begin.

To upgrade an RPI-8 to an RPI-16

1. Power down the RPI.
2. Unscrew the grounding straps and plates.

3. Add the second power supply unit (A0385554, NPS 50376L106) and screw down the grounding straps, the grounding plates, and the power supply unit.
4. Plug the output of the power supply unit into the connector board.
5. Connect the jumper lead from PSU 1 to the lead from PSU 2 (as shown below).
6. Power up the RPI.

RPI connections



Glossary

A

alarm code: A number that appears on the alarm telephone's display, informing you that the ICS has detected a fault in the system.

Analog Terminal Adapter (ATA): A device that permits the connection of analog telecommunication devices such as fax machines, answering machines, and single line telephones to the Norstar system. Programmed defaults for the ATA are automatically assigned by the Norstar system.

Answer button: A telephone button with an indicator that is used to monitor another telephone. The answer button indicates incoming calls destined for the other telephone. Someone working at a telephone with answer buttons (an attendant, for example) can receive all ringing and visual indication of incoming calls for other telephones, and answer those calls when necessary.

One telephone can have up to four Answer buttons. An Answer button is automatically assigned to a telephone when that telephone is assigned an Answer DN.

Answer DN: The internal or directory number (DN) of a telephone that is monitored by an Answer button. You can assign up to four Answer DNs to a telephone under Line Access in Terminals and Sets programming.

antenna: A built-in antenna inside each Base Station. External antennas can also be used to extend radio coverage to hard-to-reach places such as tunnels or stairwells.

Antenna type: A programming setting that lets you select the type of antenna used for each Base Station radio in your Norstar Companion system. Settings are Internal and External.

B

Base Station: A Companion component that is mounted on walls and ceilings to provide a radio link to an office or other area where Companion portable telephones are used. Each Base Station houses two radios that allow portables to send and receive calls through the ICS. See also UTAM Inc.

C

Call Forward: A feature that forwards all the calls arriving at your telephone to another telephone in your Norstar system. You can also forward calls from your Norstar Companion portable. To have calls forwarded outside the system, use Line Redirection.

Call Transfer: See Transfer.

Cell: The area covered by one or more radios in close proximity within a Norstar Companion system. Calls on portable telephones are passed from one cell to another as the user moves around the office.

Cell assignment: A heading in programming that lets you set up whether a cell has radios, any neighboring cells, or any neighboring radios.

Cell neighbor: A cell that physically adjoins another cell.

Combo Cartridge: A cartridge that allows you to connect Trunk Modules and Station Modules to the ICS to expand the system's capacity for trunks and telephones. Combo Cartridges provide six-port or 12-port expansion and Services functionality with each cartridge. (See also Expansion Cartridge.)

Companion: The name for Northern Telecom communication systems which use radio technology to transmit and receive signals between its components and the Norstar system.

Companion Wireless provides mobility in the workplace. Calls that used to ring just at your Norstar set can also appear and ring at your portable.

Companion ID: An eight character (alphanumeric) number assigned by Northern Telecom to identify each Companion wireless system. This Companion ID is sent to each customer once radio or portable credits have been purchased. The Companion ID must be provided each time keys or credits are obtained using the Nortel Customer response center.

Companion portable telephone: Hand-held wireless sets which allow complete mobility within the reach of Companion Base Stations or an external antenna. Portables offer many but not all Norstar features

and share much of the same programming as "wired" desk sets.

Conference: The Conference feature allows you to establish a three-person call at your Norstar telephone. It can also be used on your Norstar Companion portable.

credits: See Portable Credits.

D

defaults: The settings for all Norstar features when the system is first installed. Settings are changed from their defaults in programming. In this manual, default settings are shown in **bold** text.

destination code: A two- to seven-digit number that the system interprets and then translates into the digits that you want dialed out. Both the code and its associated dialed digits are assigned under Routing service in Services programming.

Directed Receive Signal Strength Indicator: A measurement of the signal strength between a portable and a specific Base Station radio. You require the 5-digit ID of the Base Station radio that you want to measure.

See also Receive Signal Strength Indicator.

Directory number (DN): A unique number that is automatically assigned to each telephone or data terminal. The DN, also referred to as an internal number, is often used to identify a telephone when settings are assigned during programming. Default DN assignments start at 221.

DN: See Directory number.

E

event message: Event messages are stored in the system log and displayed during a Maintenance session. They record a variety of events and activities in the Norstar system.

Expansion Cartridge: A cartridge that allows you to connect Trunk Modules and Station Modules to the ICS to expand the system's capacity for trunks and telephones. There are two Expansion Cartridges: a two-port Expansion Cartridge and a six-port Expansion Cartridge. (See also Combo Cartridge.)

External paging: A feature you can use to make voice announcements over an externally-mounted loudspeaker connected to the Integrated Communication System. The external speaker is not a Norstar component and must be supplied by the customer.

H

Handoff: An activity of Companion wireless components. Handoff is when the system "finds" a new cell to maintain the link between a portable telephone and the ICS.

I

ICS (integrated communication system): The central hardware component in the Norstar system. The ICS has its own processor and memory, and provides a physical point of connection for the various types of devices, telephones, and expansion modules used in Norstar.

The ICS can function on its own as a basic system (with 32 Norstar telephones and up to 48 external lines), or with the addition of Trunk Modules (TM) that supports more external lines, or Station Modules (SM) that support more Norstar telephones.

incoming line group (ILG): A group of lines used for incoming calls. Incoming line groups provide telephone access to several incoming lines without taking up many line buttons. A line is assigned to be part of an incoming line group in Installer programming.

Installer password: A one-to six-digit password that prevents unauthorized access to Installer-oriented programming. The Installer password can be assigned and changed in Passwords programming.

Integrated Services Digital Network (ISDN): A digital telephone service that allows for a combination voice and data connection over a single, high-speed connection. ISDN service can operate over the same copper twisted-pair telephone line as analog telephone service.

Intercom button: A button that provides access to internal lines used for calls within a Norstar system and access to external lines through a line pool or external code. A telephone may be assigned zero to eight Intercom buttons. This is done during an Installer programming session.

Intercom keys: See Intercom button.

K

Key Service Unit (KSU): Please see Integrated Communication System (ICS).

L

Line Pool:

Feature

A group of lines used for making external calls. Line pools provide an efficient way of giving a telephone access to external lines without taking up many line buttons. A line is assigned to be part of a line pool in an Installer programming session.

M

M7310 telephone: A telephone that has a two-line display, three display buttons, 10 programmable memory buttons with indicators, and 12 dual memory programmable buttons without indicators. An M7310 can be equipped with a Busy Lamp Field.

M7324 telephone: A telephone with a two-line display, three display buttons, and 24 programmable memory buttons with indicators. An M7324 telephone can be equipped with a CAP module.

Module: A component of the Norstar key system. Includes the Integrated Communication System, Trunk Module and Station Module.

O

OPS: Off premise station.

OPX: Off premise extension.

overlay: See Programming overlay.

P

Passwords: A programming section that lets you assign or change COS passwords, Call log passwords, or any of the programming passwords. Once you access the Passwords section, you can only modify the passwords for your level of programming.

Portable Credits (U.S. only):

Predefine the maximum number of portables that can be registered to the system. Systems can only register as many portables as there are available Portable Credits. To register additional portables, you must obtain Portable Credit Keys for the number of additional portables you need. You can obtain additional keys whenever you need to expand the number of portables, up to a maximum of 60 portables for each XC 2.0 system.

portable telephone: See Companion portable telephone.

Prime line: The line on your telephone that is automatically selected when you lift the receiver, press the Handsfree/Mute button or use an external dialing feature.

A Prime Line is assigned to a telephone during Installer programming.

Private line: See Private to.

Private to: A line can be assigned, during Installer programming, to one telephone as a private line. The line cannot appear on any other telephone, except the prime telephone for that line. Private lines cannot be placed into line pools.

programming: Setting the way the Norstar system will work. Programming includes system-wide settings and individual telephone and line settings.

programming overlay: A paper template that is placed over the top four memory buttons with indicators on the M7310 or M7324 telephone during programming. The overlay labels indicate the special function that each of the four buttons takes on during programming. The overlay is found at the back of the Norstar Companion Installer Guide or System Coordinator Guide.

R

Radio Credits (U.S. only): The XC 2.0 system recognizes Base Stations as *Radio credits*. The number of Radio Credits licenced to the system is embedded in the UTAM Activation Key. Two radio credits are needed for each Base Station.

Radio Data: The section of Companion programming that contains all the headings to set up cells and radios in your Norstar Companion system.

Receive Signal Strength Indicator (RSSI): A measurement of the signal strength that the Base Station receives from a particular portable. The strongest value is about -35 dBm; the weakest value is approximately -94 to -100 dBm.

Recovery Key (U.S. only): See UTAM Recovery Key.

Reevaluation: A heading under radio data that lets you re-assign the proper cell configuration to each

radio in a Base Station. Use it when you've added or removed Base Stations in your Norstar Companion system.

Registration: The procedure for assigning an extension on the Norstar system to a Companion portable telephone. Registration is controlled using System Coordinator programming and performed "over the air" using the portable itself.

Registration password: a password that prevents unauthorized users from registering portables on the Norstar Companion system.

Regression Key (U.S. only): Restores the previous system security number so that previously applied UTAM Activation Keys and Portable Credit Keys can be reentered to restore full system operation. Also required in cases of system recovery. This key cannot be reused.

Remote access: The ability to dial into a Norstar system from outside the system and make use of selected Norstar features. The lines, features, and dialing capabilities available to a remote user are determined by the Class of Service.

If the remote access line is answered with DISA, the user must enter a Class of Service password to gain access to the Norstar system's features.

Remote paging: This feature allows remote users to use the Norstar paging feature. Access to this feature is governed by the Class of Service for the call. See Remote Access and Class of Service.

Remote Power Interconnect (RPI)

device: An interface providing remote power for the Base Stations. Each RPI can power up to 8 or 16 Base Stations.

Routing: See Routing Service.

Routing service: A programming section that allows outgoing calls to be directed automatically based on the numbers a caller dials. For Norstar systems linked in a network, routing can create a transparent or coordinated dialing plan. It can also be used to direct calls to the least expensive lines according to a Services schedule (sometimes called least cost routing).

Roaming: Roaming is the ability of a portable telephone to make and receive calls anywhere within the coverage area of a Norstar Companion system.

RSSI: See Receive Signal Strength Indicator.

S

Software Keys (U.S. only): Keys and credits administered by UTAM Inc. to control user capacity and to ensure system location verification for unlicensed, personal wireless communication devices. They must be obtained and entered into your Norstar Companion system in order to activate wireless capability.

See also UTAM Inc.

Station Module: A module that allows you to connect up to 16 additional telephones to your Norstar system.

System Coordinator password: A one- to six-digit password that prevents unauthorized access to system programming. The system coordinator password can be assigned and changed in programming.

System Logical Identifier (LID): a 4-digit number by which the system identifies itself to portable telephones and which the portable telephones use to request service from the system. Only the Installer can change the System LID.

System ID: The System ID (or System Security number) can be accessed on any M7324 or M7310 telephone display by pressing

Feature	*	*	S	Y	S	I	D
Feature	*	*	7	9	7	4	3

The number is required in order to obtain the keys that will activate your Norstar Companion system's wireless capability.

See also Software Keys.

T

Target lines: Lines used to answer incoming calls only. A target line routes a call according to digits it receives from an incoming trunk. They are referred to by line numbers in the same way as physical lines.

Transfer: A feature that lets you redirect a call to another telephone in your Norstar system, over a network or outside your Norstar system. It also works with a Norstar Companion portable.

Trunk Module: A module that allows you to install additional Trunk

Cartridges in your system to provide up to 12 additional trunks.

Twinning: With the XC 2.0 system, the ability of users who have both a wireline (desk) telephone and Companion portable telephone to answer calls from either device. Twinning is made possible either through assigning Answer DN's or configuring target lines.

U

Undirected Receive Signal Strength Indicator:

A measurement of the signal strength between a portable and the Base Station radio that the portable is currently linked to.

See also Receive Signal Strength Indicator.

UTAM Activation Key (U.S. only):

Activates the wireless capability on a new system and in system upgrades involving a change to the number of Base Stations supported.

UTAM Inc. (U.S. only): The Federal Communications Commission (FCC) has appointed UTAM Inc. as the body responsible for coordinating and verifying the installation or relocation of personal wireless communication devices operating between 1.92 GHz and 1.93 GHz. This allows UTAM Inc. to monitor and control the level of wireless activity within this band for a specified geographical location.

UTAM Recovery Key (U.S. only):

Reactivates a Companion wireless system that has been disabled and restores the Companion system to its previous radio credit capacity. See the troubleshooting chapter.

W

wireless: See Companion.

Index

A

activating

- disabled system 1, 64
- wireless communication 1, 64, 88

activation key (see UTAM)

alarm code

- Alarm 200 89
- Alarm 201 89
- Alarm 202 90
- Alarm 203 90
- Alarm 204 90
- Alarm 205 90
- Alarm 206 90
- Alarm 207 90
- Alarm 208 90
- Alarm 209 90
- Alarm 21 89
- Alarm 22 89
- Alarm 53 89
- Alarm 54 89
- Alarm 55 89
- Alarm 68 89
- Radio cred req'd 93
- Re-Eval recommended 91
- Re-Eval required 90
- UTAM key req'd 91
- UTAM test failed 92

antenna

- bracket 37
- external installation 34–39
- lightning surge protector
 - part number 102
 - technical specifications 102
- outdoor installation 34–39

- technical specifications 101
- type, selecting 62

B

backup power 18

Base Station

- clearance 31
- conducted emissions 1
- configuring
 - general 67
 - on a maxi system 8, 10
 - on a mega system 11
 - on a midi system 8
 - on a mini system 8
- connecting to Station Module 7
- DC loop resistance 84
- disabling 85
- display messages
 - UTAM code req'd 41
 - UTAM test failed 41
- hand-off 29
- installation
 - connecting to ICS 7, 9–12
 - mounting 30–32
 - planning 18, 29
 - powering up 41
 - updating software for 41
 - warning 1
- planning
 - locations 7
 - port allocation 18
- plug-top power supply 100
 - connecting to Base Station 32
 - part number 100

- technical specifications 100
- port numbering 14–15
- positioning 29–30
- radiated emissions 1
- radio credits 29
- red light 82, 83
- replacing 85
- signal strength (see Receive Signal Strength Indicator)
- site planning 29
- specifications 100
- termination board 32
- testing 81
- troubleshooting 83–84
- using in US 3
- UTAM recognition of 29
- wiring length
 - power pair(s) 22
 - TCM lines 83
- bracket
 - antenna 37
 - lightning surge arrestor 38

C

- C3050 portables
 - deregistration 71–72
 - registration 69–71
- cells (see Companion, cells)
- clearance
 - Base Station 31
 - RPI 20
- Combo Cartridge, installation planning 8
- Companion
 - antenna 62
 - Base Stations 3, 29
 - cells, programming
 - cell neighbors 62

- cell rad neighbor 62
- cell radios 62
- cells, assignment 61
- coverage area 3
- Diagnostic Software 4
- ID 64
- portable telephone (see portable telephone)
- programming 43–68
- Provisioning Record 29
- re-evaluation 60
 - scheduled 61
 - status 61
- registration 58–61
- system logical identifier 63
- wireless
 - on a maxi system 8, 10
 - on a mega system 11
 - on a midi system 8
 - on a mini system 8
- conducted emissions 1
- connecting expansion modules 9, 10, 13

D

- default
 - password 49
 - Startup 49
 - system programming 50
 - template, changing 52
- deregistration
 - C3050 portables 71–72
- diagnostics, running on remote system 4
- directory numbers, entering 48
- disabled system, activating 64
- display buttons 47

E

equipment and supplies

installation checklist 7

event message

Evt 275-3546 S8 94

Evt 301-1031 S5 94

Evt 302-1031 S5 94

Evt 303-1031 S5 94

Evt 304-01032 94

Evt 305-01032 S5 95

Evt 306-01031 S5 95

Evt 307-0109100 S5 95

Evt 307-0109101 S5 95

Evt 307-0109102 S5 95

Evt 308-0103 S8 95

Evt 664 S8 95

Evt 665 S4 95

Evt 666 S5 96

Evt 667 S5 96

Evt 668 S5 96

Evt 669 S5 96

Evt 670 S5 96

Evt 671 S5 96

Evt 672 S5 96

Evt 673 S5 96

Evt 675 S5 96

Evt 831 S5 96

Evt 832 S5 96

Evt 833 S5 96

Evt 834 S5 96

Evt 835 S5 96

Evt 836 S5 96

Evt 837 S5 96

Evt 840 S5 96

Evt 841 S5 97

Evt 842 S5 97

Evt 843 S5 97

Evt 848 S5 97

Evt 849 S5 97

Evt 850 S5 97

Evt 851 S5 97

Evt 852 S5 97

Evt 853 S5 97

Evt 854 S5 97

Evt 855 S5 97

Evt 856 S5 97

Evt 859 S5 97

Evt 864 S5 97

Evt 865 S5 97

Evt 869 S5 97

Evt 870 S5 98

Evt 871 S5 98

Evt 872 S5 98

Evt 873 S5 98

Evt 877 S5 98

Evt 878 S5 98

Evt 879 S5 98

Evt 881 S5 98

Evt 884 S5 98

Evt 885 S5 98

Evt 886 S5 98

Evt 887 S5 98

Evt 888 S5 98

Expansion Cartridge

installation planning 8

six-port 10

twelve-port 11

two-port 9

expansion equipment

installation checklist 8

expansion modules

connecting 9, 13, 18

installation 10

routing fibers for 13

external antenna

installing 34-39

technical specifications 101

external antenna (see also
antenna)
external paging
and portable telephones 55

F

Feature

* * S T A R T U P

Startup 51

features

Norstar 54

portable 54

Federal Communications

Commission (FCC)

certification, antennas 34

designation of UTAM Inc. 1

I

ICS (see Integrated
Communication System)

indicators

telephone buttons 47

initializing the system

Startup programming 51–52

installation

Base Station 1, 7, 18, 29–
32

checklist 7, 17

Combo Cartridge 8

configuring expansion
modules 8

equipment and supplies
checklist 7

Expansion Cartridge 8

expansion modules 18

external antenna 34–39

lightning surge arrestor 34–
39

planning 7–15

RPI 18–25

Station Module 7

Installer

entering programming 53

password 51

installing equipment

external antenna 34–39

Integrated Communication
System (ICS) 8

numbering 14

software 3

invalid code

UTAM 67

K

keys

activation (see UTAM)

recovery (see UTAM)

UTAM 64

KSU (Key Service Unit) see ICS
(Integrated Communication
System)

L

LID (see system logical
identifier)

lightning protection 2

lightning surge arrestor

bracket 38

installation 35

installing 34–39

lightning surge arrestors 34

lightning surge protector
specifications 102

line numbers

entering 48

M

- maxi system, configuring Base Station 8, 10
- mega system, configuring Base Station 11
- midi system, configuring Base Station 8
- mini system, configuring Base Station 8
- module numbering
 - six-port Expansion Cartridge 14
 - twelve-port Expansion Cartridge 15
 - two-port Expansion Cartridge 14
- mounting
 - RPI 20

N

- non-expanded system (ICS alone) numbering 14
- Norstar
 - features 54
- Norstar display buttons 47
- Norstar Programming Record 47
- Norstar Remote Utilities (NRU)
 - using to program system 4
- Norstar Voice Mail, system requirements 4
- Norstar XC 2.0
 - software 3
- Nortel Customer Response Center 64, 88
 - installing Base Stations 29
 - verifying UTAM wireless approval 29

- numbers
 - entering directory numbers 48
 - entering line numbers 48

O

- outdoor antenna
 - technical specifications 101

P

- paging
 - from portable telephones 55
- password
 - capabilities 43
 - defaults 49
 - Installer 51
 - System Coordinator 45
 - System Coordinator Plus 44
- plug-top power supply 100
- port allocation 18
- portable DNs 58
- portable registration 67
- portable telephone
 - deregistration 71–72
 - description 3
 - DN range 33
 - features 54
 - installing 33
 - registration 33, 69–71
 - signal strength (see Receive Signal Strength Indicator)
 - system maximum 33
 - testing 81
 - troubleshooting 83
 - using in US 4
- power backup, for RPI 19
- power supply
 - for an RPI 19

- plug-top 100
- powering up
 - startup messages for Base Stations 41
- programming
 - Companion 43–68
 - controlling access 43
 - entering for Installers 53
 - entering for System Coordinators 53–54
 - entering with other passwords 54
 - exiting 48
 - overlay 45–47
 - overview 44–45
 - registration for portable telephones 58–61
 - Startup 51–52
 - system 43–68
 - system logical identifier 63
 - tools 45
 - using Norstar Remote Utilities (NRU) 4
 - viewing updates 48
- programming basics
 - access 43
 - indicators, telephone buttons 47
 - special characters 47
- programming record 47
- provisioning record 29
 - using 7

R

- radiated emissions 1
- radio credits 61
- Receive Signal Strength Indicator
 - C3020, directed 77

- C3020, undirected 76
- C3050, directed 73
- C3050, undirected 72
- re-evaluation (see Companion re-evaluation)
- registration
 - C3050 portables 69–71
 - disabling 58–61
 - enabling 58–61
- regulations
 - radiated/conducted emissions 1
- Remote Power Interconnect (see RPI)
- replacing a Base Station 85
- RPI (Remote Power Interconnect)
 - backup power requirements 18
 - cabling distance 22
 - clearance 20
 - DC loop resistance 22, 84
 - illustration
 - closed unit 19
 - components 22
 - open unit 22
 - opening 21
 - installing 18–27
 - part number 99
 - power supply 19
 - power supply unit (PSU)
 - installing a second PSU 103
 - technical specifications 99
 - troubleshooting 86
 - upgrading RPI-8 to RPI-16 22
 - wiring 22–29
 - input connections 24
 - output connections 24

RPI-16 BIX UL, capacity 19
 RPI-8 BIX UL
 upgrading to RPI-16 BIX UL 103
 RPI-8 BIX UL, capacity 19
 RSSI (see Receive Signal Strength Indicator)

S

safety 2
 signal strength (see Receive Signal Strength Indicator)
 six-port Expansion Cartridge 10, 14
 software keys 64
 software, ICS and Norstar XC 2.0 3
 special characters 47
 Startup
 defaults 49
 programming 51–52
 Station Module
 Base Station capacity 7
 installation planning 7
 SysID
 loss of 87
 recording 88
 system
 activating 88
 activation 1, 64
 programming 43–68
 requirements for Norstar Voice Mail 4
 testing coverage 82
 upgrading 103
 System Coordinator password 45
 System Coordinator Plus password 44

System Coordinators
 entering programming 53–54
 system logical identifier 63
 system prgrmg defaults 50

T

TCM connections
 Base Stations 31
 polarity of 31
 technical specifications
 antenna 101
 Base Station 100
 conducted emissions 1
 plug-top power supply 100
 radiated emissions 1
 RPI 99
 template
 changing default 52
 testing
 Base Station 81
 portable telephone 81
 system coverage 82
 troubleshooting
 Base Station 83–84
 portable telephone 83
 Remote Power Interconnect 86
 twelve-port Expansion Cartridge 11
 module numbering 15
 twinning 3
 two-port Expansion Cartridge 9
 module numbering 14

U

uninterruptible power supply (see UPS)

upgrading

system 103

upgrading, RPI-8 to RPI-16 (see
RPI-8 BIX UL)

UPS (uninterruptible power
supply) 18

UTAM

activation code

invalid code 67

activation key 64

approval 1, 7, 29

recovery key 64, 68

regression key 68, 87–88

V

viewing programming 48

Voice Mail, system requirements
4

W

wireless capabilities (see
Companion)

wireless communication

activation approval 1, 64, 88

regression key 87–88

wireless equipment 29

wireless, antenna installation
34–39

wiring

RPI 18–29

Tell us what you think...

This is your document. Nortel wants it to work well for you.

Please take a few minutes to answer the questions on the other side of this page. Fax it back to us at the number provided, or mail it to the address below.

Your comments will be used to make improvements.

Thank you. We appreciate your time and consideration.

Nortel Product Training and Documentation

Return mail address:

Documentation User Comments Survey
Nortel Product Training and Documentation
P.O. Box 833858
M/S H300
Richardson, TX 75083-3858
USA

Tell us what you think...

Fax to:

Documentation User Comments Survey
Nortel Product Training and Documentation
1-972-684-8699

Please circle the most appropriate number on the scale for each question.

1. Overall, are you satisfied with this document?

Yes 7 6 5 4 3 2 1 No

2. Is it easy to find information in this document?

Yes 7 6 5 4 3 2 1 No

3. Have you found the information in this document to be technically accurate?

Yes 7 6 5 4 3 2 1 No

4. Is this document clearly written?

Yes 7 6 5 4 3 2 1 No

5. Is the information in this document complete for its purpose?


Yes 7 6 5 4 3 2 1 No



6. Does this document help you do your job?

Yes 7 6 5 4 3 2 1 No

Comments:

Optional: Your name _____ Fax _____
Company _____





After you have finished programming, store your Norstar Programming Overlay in the slots provided on the back cover.

Après avoir terminé la programmation, rangez la grille Norstar dans les fentes prévues à cet effet à la fin de ce guide.

Cuando haya terminado de programar, inserte en estas ranuras su Plantilla de programación Norstar que se encuentra en la contra tapa.

